




YAMAHA

OWNER'S MANUAL

XMAX

MOTORCYCLE

 Read this manual carefully before operating this vehicle.

CZD300J

LIT-11626-31-28

B74-F8199-10

EAU10043

⚠ WARNING

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

YAMAHA

LIT-CALIF-65-01

⚠ Read this manual carefully before operating this vehicle. This manual should stay with this vehicle if it is sold.

Congratulations on your purchase of the Yamaha CZD300J. This model is the result of Yamaha's vast experience in the production of fine sporting, touring, and pace-setting racing machines. It represents the high degree of craftsmanship and reliability that have made Yamaha a leader in these fields.

This manual will give you an understanding of the operation, inspection, and basic maintenance of this scooter. If you have any questions concerning the operation or maintenance of your scooter, please consult a Yamaha dealer.

The design and manufacture of this Yamaha scooter fully comply with the emissions standards for clean air applicable at the date of manufacture. Yamaha has met these standards without reducing the performance or economy of operation of the scooter. To maintain these high standards, it is important that you and your Yamaha dealer pay close attention to the recommended maintenance schedules and operating instructions contained within this manual.

Yamaha continually seeks advancements in product design and quality. Therefore, while this manual contains the most current product information available at the time of printing, there may be minor discrepancies between your scooter and this manual. If there is any question concerning this manual, please consult a Yamaha dealer.

EWA12082





WARNING

Please read this manual and the "YOU AND YOUR MOTORCYCLE: RIDING TIPS" booklet carefully and completely before operating this scooter. Do not attempt to operate this scooter until you have attained adequate knowledge of its controls and operating features and until you have been trained in safe and proper riding techniques. Regular inspections and careful maintenance, along with good riding skills, will ensure that you safely enjoy the capabilities and reliability of this scooter.

Important manual information

EAU63350

Particularly important information is distinguished in this manual by the following notations:

	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.
 WARNING	A WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.
NOTICE	A NOTICE indicates special precautions that must be taken to avoid damage to the vehicle or other property.
TIP	A TIP provides key information to make procedures easier or clearer.

*Product and specifications are subject to change without notice.

EAU0770

**CZD300J
OWNER'S MANUAL
©2017 by Yamaha Motor Corporation,
U.S.A.
1st edition, May 2017
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Corporation, U.S.A.
is expressly prohibited.
Printed in Indonesia.
P/N LIT-11626-31-28**

Table of contents

Location of important labels	1-1
Safety information	2-1
Further safe-riding points.....	2-5
Description	3-1
Left view	3-1
Right view.....	3-2
Controls and instruments.....	3-3
Smart key system	4-1
Smart key system.....	4-1
Part 15 of FCC Rules.....	4-2
Operating range of the smart key system	4-3
Handling of the smart key and mechanical keys	4-4
Smart key	4-6
Replacing the smart key battery	4-7
Main switch	4-8
Instrument and control functions	5-1
Indicator lights and warning lights	5-1
Speedometer.....	5-2
Tachometer	5-3
Multi-function display.....	5-3
Handlebar switches.....	5-11
Front brake lever	5-13
Rear brake lever	5-13
ABS	5-14
Traction control system.....	5-15
Fuel tank cap.....	5-16
Fuel.....	5-17
Fuel tank overflow hose	5-19
Catalytic converters	5-19
Storage compartments	5-20
Windshield.....	5-22
Handlebar position	5-24
Adjusting the shock absorber assemblies.....	5-25
Sidestand	5-26
Ignition circuit cut-off system.....	5-26
Auxiliary DC jack	5-28

For your safety – pre-operation checks	6-1
---	-----

Operation and important riding points	7-1
Starting the engine.....	7-2
Starting off	7-3
Acceleration and deceleration	7-3
Braking.....	7-4
Tips for reducing fuel consumption.....	7-4
Engine break-in.....	7-5
Parking.....	7-5

Periodic maintenance and adjustment	8-1
Owner's tool kit.....	8-2
Periodic maintenance chart for the emission control system.....	8-3
General maintenance and lubrication chart.....	8-4
Removing and installing the panel	8-7
Checking the spark plug.....	8-8
Canister.....	8-9
Engine oil and oil filter element.....	8-9
Final transmission oil	8-12
Coolant	8-13
Air filter and V-belt case air filter elements	8-14
Checking the throttle grip free play	8-18
Valve clearance.....	8-19
Tires	8-19
Cast wheels	8-21
Checking the front and rear brake lever free play	8-22
Checking the front and rear brake pads.....	8-23
Checking the brake fluid level.....	8-23
Changing the brake fluid.....	8-24
Checking the V-belt	8-25
Checking and lubricating the cables	8-25
Checking and lubricating the throttle grip and cable	8-26


Table of contents

Lubricating the front and rear brake levers.....	8-26
Checking and lubricating the centerstand and sidestand	8-27
Checking the front fork.....	8-27
Checking the steering.....	8-28
Checking the wheel bearings	8-28
Battery	8-29
Replacing the fuses.....	8-30
Headlights	8-32
Auxiliary lights.....	8-32
Brake/tail light.....	8-33
Replacing a turn signal light bulb	8-33
Replacing the license plate light bulb	8-34
Troubleshooting.....	8-35
Troubleshooting charts.....	8-36
Emergency mode	8-38
Scooter care and storage	9-1
Matte color caution	9-1
Care.....	9-1
Storage.....	9-4
Specifications.....	10-1
Consumer information.....	11-1
Identification numbers.....	11-1
Diagnostic connector	11-2
Vehicle data recording.....	11-2
Reporting safety defects	11-3
Scooter noise regulation	11-4
Maintenance record	11-5
YAMAHA MOTOR CORPORATION, U.S.A. 2015 AND LATER MODEL STREET & DUAL-PURPOSE MOTORCYCLE LIMITED WARRANTY	11-6
YAMAHA EXTENDED SERVICE (Y.E.S.)	11-8
Index.....	12-1

Location of important labels

EAU63360

Read and understand all of the labels on your vehicle. They contain important information for safe and proper operation of your vehicle. Never remove any labels from your vehicle. If a label becomes difficult to read or comes off, a replacement label is available from your Yamaha dealer.



Location of important labels


1



2




3




4



5



6




Location of important labels


7



8



9





Safety information

EAJ1026B

2

Be a Responsible Owner

As the vehicle's owner, you are responsible for the safe and proper operation of your scooter.

Scooters are single-track vehicles. Their safe use and operation are dependent upon the use of proper riding techniques as well as the expertise of the operator. Every operator should know the following requirements before riding this scooter.

He or she should:

- Obtain thorough instructions from a competent source on all aspects of scooter operation.
- Observe the warnings and maintenance requirements in this Owner's Manual.
- Obtain qualified training in safe and proper riding techniques.
- Obtain professional technical service as indicated in this Owner's Manual and/or when made necessary by mechanical conditions.
- Never operate a scooter without proper training or instruction. Take a training course. Beginners should receive training from a certified instructor. Contact an authorized scooter dealer to find out about the training courses nearest you.

Safe Riding

Perform the pre-operation checks each time you use the vehicle to make sure it is in safe operating condition. Failure to inspect or maintain the vehicle properly increases the possibility of

an accident or equipment damage. See page 6-1 for a list of pre-operation checks.

- This scooter is designed to carry the operator and a passenger.
- The failure of motorists to detect and recognize scooters in traffic is the predominating cause of automobile/scooter accidents. Many accidents have been caused by an automobile driver who did not see the scooter. Making yourself conspicuous appears to be very effective in reducing the chance of this type of accident.

Therefore:

- Wear a brightly colored jacket.
- Use extra caution when you are approaching and passing through intersections, since intersections are the most likely places for scooter accidents to occur.
- Ride where other motorists can see you. Avoid riding in another motorist's blind spot.
- Never maintain a scooter without proper knowledge. Contact an authorized scooter dealer to inform you on basic scooter maintenance. Certain maintenance can only be carried out by certified staff.
- Many accidents involve inexperienced operators. In fact, many operators who have been involved in accidents do not even have a current driver's license.
- Make sure that you are qualified and that you only lend your scooter to other qualified operators.



Safety information

2

- Know your skills and limits. Staying within your limits may help you to avoid an accident.
- We recommend that you practice riding your scooter where there is no traffic until you have become thoroughly familiar with the scooter and all of its controls.
- Many accidents have been caused by error of the scooter operator. A typical error made by the operator is veering wide on a turn due to excessive speed or undercornering (insufficient lean angle for the speed).
- Always obey the speed limit and never travel faster than warranted by road and traffic conditions.
- Always signal before turning or changing lanes. Make sure that other motorists can see you.
- The posture of the operator and passenger is important for proper control.
- The operator should keep both hands on the handlebar and both feet on the operator footrests during operation to maintain control of the scooter.
- The passenger should always hold onto the operator, the seat strap or grab bar, if equipped, with both hands and keep both feet on the passenger footrests. Never carry a passenger unless he or she can firmly place both feet on the passenger footrests.
- Never ride under the influence of alcohol or other drugs.

- This scooter is designed for on-road use only. It is not suitable for off-road use.

Protective Apparel

The majority of fatalities from scooter accidents are the result of head injuries. The use of a safety helmet is the single most critical factor in the prevention or reduction of head injuries.

- Always wear an approved helmet.
- Wear a face shield or goggles. Wind in your unprotected eyes could contribute to an impairment of vision that could delay seeing a hazard.
- The use of a jacket, substantial shoes, trousers, gloves, etc., is effective in preventing or reducing abrasions or lacerations.
- Never wear loose-fitting clothes, otherwise they could catch on the control levers or wheels and cause injury or an accident.
- Always wear protective clothing that covers your legs, ankles, and feet. The engine or exhaust system become very hot during or after operation and can cause burns.
- A passenger should also observe the above precautions.

Avoid Carbon Monoxide Poisoning

All engine exhaust contains carbon monoxide, a deadly gas. Breathing carbon monoxide can cause headaches, dizziness, drowsiness, nausea, confusion, and eventually death.

Carbon Monoxide is a colorless, odorless, tasteless gas which may be present even if you do not see or smell any

Safety information

2 engine exhaust. Deadly levels of carbon monoxide can collect rapidly and you can quickly be overcome and unable to save yourself. Also, deadly levels of carbon monoxide can linger for hours or days in enclosed or poorly ventilated areas. If you experience any symptoms of carbon monoxide poisoning, leave the area immediately, get fresh air, and SEEK MEDICAL TREATMENT.

- Do not run engine indoors. Even if you try to ventilate engine exhaust with fans or open windows and doors, carbon monoxide can rapidly reach dangerous levels.
- Do not run engine in poorly ventilated or partially enclosed areas such as barns, garages, or carports.
- Do not run engine outdoors where engine exhaust can be drawn into a building through openings such as windows and doors.

Loading

Adding accessories or cargo to your scooter can adversely affect stability and handling if the weight distribution of the scooter is changed. To avoid the possibility of an accident, use extreme caution when adding cargo or accessories to your scooter. Use extra care when riding a scooter that has added cargo or accessories. Here, along with the information about accessories below, are some general guidelines to follow if loading cargo to your scooter:

The total weight of the operator, passenger, accessories and cargo must not exceed the maximum load limit.

Operation of an overloaded vehicle could cause an accident.

Maximum load:

161 kg (355 lb)

When loading within this weight limit, keep the following in mind:

- Cargo and accessory weight should be kept as low and close to the scooter as possible. Securely pack your heaviest items as close to the center of the vehicle as possible and make sure to distribute the weight as evenly as possible on both sides of the scooter to minimize imbalance or instability.
- Shifting weights can create a sudden imbalance. Make sure that accessories and cargo are securely attached to the scooter before riding. Check accessory mounts and cargo restraints frequently.
- Properly adjust the suspension for your load (suspension-adjustable models only), and check the condition and pressure of your tires.
- Never attach any large or heavy items to the handlebar, front fork, or front fender. Such items can create unstable handling or a slow steering response.
- **This vehicle is not designed to pull a trailer or to be attached to a sidecar.**



Genuine Yamaha Accessories

Choosing accessories for your vehicle is an important decision. Genuine Yamaha accessories, which are available only from a Yamaha dealer, have been designed, tested, and approved by Yamaha for use on your vehicle.

Many companies with no connection to Yamaha manufacture parts and accessories or offer other modifications for Yamaha vehicles. Yamaha is not in a position to test the products that these aftermarket companies produce. Therefore, Yamaha can neither endorse nor recommend the use of accessories not sold by Yamaha or modifications not specifically recommended by Yamaha, even if sold and installed by a Yamaha dealer.

Aftermarket Parts, Accessories, and Modifications

While you may find aftermarket products similar in design and quality to genuine Yamaha accessories, recognize that some aftermarket accessories or modifications are not suitable because of potential safety hazards to you or others. Installing aftermarket products or having other modifications performed to your vehicle that change any of the vehicle's design or operation characteristics can put you and others at greater risk of serious injury or death. You are responsible for injuries related to changes in the vehicle. Keep the following guidelines in mind, as well as those provided under "Loading" when mounting accessories.

- Never install accessories or carry cargo that would impair the performance of your scooter. Careful-

ly inspect the accessory before using it to make sure that it does not in any way reduce ground clearance or cornering clearance, limit suspension travel, steering travel or control operation, or obscure lights or reflectors.

- Accessories fitted to the handlebar or the front fork area can create instability due to improper weight distribution or aerodynamic changes. If accessories are added to the handlebar or front fork area, they must be as lightweight as possible and should be kept to a minimum.
- Bulky or large accessories may seriously affect the stability of the scooter due to aerodynamic effects. Wind may attempt to lift the scooter, or the scooter may become unstable in cross winds. These accessories may also cause instability when passing or being passed by large vehicles.
- Certain accessories can displace the operator from his or her normal riding position. This improper position limits the freedom of movement of the operator and may limit control ability, therefore, such accessories are not recommended.
- Use caution when adding electrical accessories. If electrical accessories exceed the capacity of the scooter's electrical system, an electric failure could result, which could cause a dangerous loss of lights or engine power.

Safety information

Aftermarket Tires and Rims

The tires and rims that came with your scooter were designed to match the performance capabilities and to provide the best combination of handling, braking, and comfort. Other tires, rims, sizes, and combinations may not be appropriate. Refer to page 8-19 for tire specifications and more information on replacing your tires.

Transporting the Scooter

Be sure to observe following instructions before transporting the scooter in another vehicle.


- Remove all loose items from the scooter.
- Point the front wheel straight ahead on the trailer or in the truck bed, and choke it in a rail to prevent movement.
- Secure the scooter with tie-downs or suitable straps that are attached to solid parts of the scooter, such as the frame or upper front fork triple clamp (and not, for example, to rubber-mounted handlebars or turn signals, or parts that could break). Choose the location for the straps carefully so the straps will not rub against painted surfaces during transport.
- The suspension should be compressed somewhat by the tie-downs, if possible, so that the scooter will not bounce excessively during transport.

Further safe-riding points

EAU57600

- Be sure to signal clearly when making turns.
- Braking can be extremely difficult on a wet road. Avoid hard braking, because the scooter could slide. Apply the brakes slowly when stopping on a wet surface.
- Slow down as you approach a corner or turn. Once you have completed a turn, accelerate slowly.
- Be careful when passing parked cars. A driver might not see you and open a door in your path.
- Railroad crossings, streetcar rails, iron plates on road construction sites, and manhole covers become extremely slippery when wet. Slow down and cross them with caution. Keep the scooter upright, otherwise it could slide out from under you.
- The brake pads or linings could get wet when you wash the scooter. After washing the scooter, check the brakes before riding.
- Always wear a helmet, gloves, trousers (tapered around the cuff and ankle so they do not flap), and a brightly colored jacket.
- Do not carry too much luggage on the scooter. An overloaded scooter is unstable. Use a strong cord to secure any luggage to the carrier (if equipped). A loose load will affect the stability of the scooter and could divert your attention from the road. (See page 2-3.)

Left view




1. Storage compartment A (page 5-20)
2. Owner's tool kit (page 8-2)
3. Grab bar (page 7-3)
4. Air filter element (page 8-14)
5. Spring preload adjuster (page 5-25)
6. Final transmission oil filler cap (page 8-12)
7. Final transmission oil drain bolt (page 8-12)
8. V-belt case air filter element (page 8-14)
9. Engine oil drain bolt (page 8-9)
10. Engine oil filter element (page 8-9)
11. Sidestand (page 5-26)
12. Spark plug (page 8-8)
13. Coolant reservoir (page 8-13)

Description


EAU63391

Right view



1. Rear storage compartment (page 5-20)
2. Fuel tank cap (page 5-16)
3. Storage compartment B (page 5-20)
4. Windshield (page 5-22)
5. Battery (page 8-29)
6. Fuses (page 8-30)
7. Centerstand (page 8-27)
8. Engine oil level check window (page 8-9)
9. Engine oil filler cap (page 8-9)

Controls and instruments




1. Rear brake lever (page 5-13)
2. Left handlebar switches (page 5-11)
3. Rear brake fluid reservoir (page 8-23)
4. Speedometer (page 5-2)
5. Multi-function display (page 5-3)
6. Tachometer (page 5-3)
7. Front brake fluid reservoir (page 8-23)
8. Right handlebar switches (page 5-11)
9. Front brake lever (page 5-13)
10. Throttle grip (page 8-18)
11. Main switch (page 4-8)
12. Auxiliary DC jack (page 5-28)

Smart key system


EALJ76444

Smart key system

The smart key system enables you to operate the vehicle without using a mechanical key. In addition, there is an answer-back function to help you locate the vehicle in a parking lot. (See page 4-6.)



1. Smart key
2. Smart key button



1. Main switch
2. Main switch knob




WARNING

EWA14704

- Keep implanted pacemakers or cardiac defibrillators, as well as other electric medical devices away from the vehicle mounted antenna (see illustration).
- Radio waves transmitted by the antenna may affect the operation of such devices when close by.

- If you have an electric medical device, consult a doctor or the device manufacturer before using this vehicle.



1. Vehicle mounted antenna

ECA24080

NOTICE

The smart key system uses weak radio waves. The smart key system may not work in the following situations.

- The smart key is placed in a location exposed to strong radio waves or other electromagnetic noise
- There are facilities nearby that are emitting strong radio waves (TV or radio towers, power plants, broadcasting stations, airports, etc.)
- You are carrying or using communication equipment such as radios or mobile phones in close proximity of the smart key
- The smart key is in contact with or covered by a metallic object
- Other vehicles equipped with a smart key system are nearby

In such situations, move the smart key to another location and perform the operation again. If it still does not work, operate the vehicle in emergency mode. (See page 8-38.)

TIP

To preserve vehicle battery power, the smart key system turns off approximately 9 days after the vehicle was last used (the answer-back function is disabled). In this situation, simply push the main switch knob to turn the smart key system back on.

Part 15 of FCC Rules

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of this device.

FCC WARNING



Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Smart key system

EAUJ76450

Operating range of the smart key system

The operating range of the smart key system is about 80 cm (31.5 in) from the main switch.




- Placing the smart key in the front or rear storage compartment may block communication between the smart key and the vehicle. If the rear storage compartment is locked with the smart key inside, the smart key system may be disabled. The smart key should always be carried with you.
- When leaving the vehicle, make sure you lock the steering and take the smart key with you. It is recommended that you turn the smart key off.


TIP

- As the smart key system uses weak radio waves, the operating range may be affected by the surrounding environment.
- When the battery of the smart key is discharged, the smart key may not work or its operating range may become very small.
- If the smart key is turned off, the vehicle will not recognize the smart key even if it is within operating range. If the smart key system does not operate, see page 4-6 and confirm that the smart key is turned on.

Handling of the smart key and mechanical keys



1. Smart key
2. Mechanical key



1. Identification number card
2. Smart key (inside)
3. Identification number

WARNING

- The smart key should be carried with you. Do not store it on the vehicle.
- When the smart key is within operating range, exercise due care because other people not carrying the smart key can start the engine and operate the vehicle.

Included with the vehicle is one smart key, two mechanical keys, and one identification number card. The identification number can also be found on the inside of the smart key itself.

If the vehicle battery is discharged, the mechanical key can be used to open the seat. **Carry one mechanical key in addition to the smart key.**

If the smart key is lost or the smart key battery has discharged, the identification number can be used to operate the vehicle in emergency mode. (See page 8-38.) **Write down the identification number in case of emergency.**

If the smart key is lost and the smart key system identification number is unknown, the entire smart key system will need to be replaced at considerable cost. **Keep the identification number card in a safe place.**

ECA21573

NOTICE

The smart key has precision electronic components. Observe the following precautions to prevent possible malfunction or damage.

- Do not place or store the smart key in a storage compartment. The smart key may be damaged from road vibrations or excessive heat.
- Do not drop, bend, or subject the smart key to strong impacts.
- Do not submerge the smart key in water or other liquids.
- Do not place heavy items or excessive stress on the smart key.

Smart key system


- Do not leave the smart key in a place exposed to direct sunlight, high temperature or high humidity.
- Do not grind or attempt to modify the smart key.
- Keep the smart key away from strong magnetic fields and magnetic objects such as key holders, TVs, and computers.
- Keep the smart key away from electric medical equipment.
- Do not allow oils, polishing agents, fuel, or any strong chemicals to come in contact with the smart key. The smart key body may become discolored or cracked.
- You can register up to six smart keys for the same vehicle. See a Yamaha dealer regarding spare smart keys.
- If a smart key is lost, contact a Yamaha dealer immediately to prevent the vehicle from being stolen.

TIP

- The smart key battery life is approximately two years, but this may vary according to operating conditions.
- Replace the smart key battery when the smart key system indicator light flashes for 20 seconds when the vehicle is turned on, or when the smart key indicator light does not come on when the smart key button is pushed. (See page 4-7.) After changing the smart key battery, if the smart key system still does not operate, check the vehicle battery and then have a Yamaha dealer check the vehicle.
- If the smart key continually receives radio waves, the smart key battery will discharge quickly. (For example, when placed in the vicinity of electrical products such as televisions, radios, or computers.)

Smart key

EAU76471



1. Smart key indicator light
2. Smart key button

To turn the smart key on or off

Push the smart key button for approximately 1 second to turn the smart key on or off. When the smart key is turned off, the vehicle cannot be operated even if the smart key is within operating range. To operate the vehicle, turn the smart key on and bring it within operating range.

To check whether the smart key is turned on or off

Push the smart key button to confirm the current operating status of the smart key.

If the smart key indicator light:

- Short flash (0.1 seconds): The smart key is turned on.
- Long flash (0.5 seconds): The smart key is turned off.

Remote answer-back function

Push the smart key button to operate the answer-back function remotely. The beeper will sound twice and all of the turn signal lights will flash twice.

This feature is convenient for locating your vehicle in a parking lot and other areas.

To turn the answer-back beeper on or off

The beeper, which sounds when the answer-back function is operated, can be turned on or off according to the following procedure.

1. Turn the smart key on and bring it within operating range.
2. Turn the main switch to "OFF", and then push the main switch knob once.
3. Within 9 seconds of pushing the knob, push and hold the knob again for 5 seconds.
4. When the beeper sounds, the setting is complete.

If the beeper:

- Sounds twice: The beeper is turned off.
- Sounds once: The beeper is turned on.


Smart key system

EAUJ76481

Replacing the smart key battery

Replace the battery in the following situations.

- The smart key system indicator light flashes for about 20 seconds when the power of the vehicle is turned on.
- The answer-back function does not operate when the smart key button is pushed.



1. Smart key system indicator light "B"

ECA14724



WARNING

- The battery and other removable parts may cause injury if swallowed. Keep the battery and other removable parts away from children.
- Do not expose the battery to direct sunlight or other heat sources.

ECA15784

NOTICE

- Use a cloth when opening the smart key case with a screwdriver. Direct contact with hard objects may damage or scratch the smart key.


- Take precautions to prevent the waterproof seal from being damaged or contaminated by dirt.
- Do not touch the internal circuits and terminals. This may cause malfunctions.
- Do not apply excessive force to the smart key when replacing the battery.
- Make sure the battery is installed correctly. Confirm the direction of the positive "+" side of the battery.

To replace the smart key battery

1. Open the smart key case as shown.



2. Remove the battery.



1. Battery

TIP

Dispose of the removed battery in accordance with local regulations.

3. Install a new battery as shown.
Note the polarity of the battery.


Specified battery:
CR2032




1. Battery

4. Gently snap the smart key case closed.

Main switch



1. Main switch knob
2. Main switch lever



1. Smart key system indicator light "4"

The main switch is used to turn the vehicle power on and off, lock and unlock the steering, and open the seat, fuel tank cap lid and storage compartment A. After pushing the main switch knob and confirmation with the smart key has taken place, the main switch can be turned while the smart key system indicator light is on (approximately 4 seconds).

EWA18720

WARNING

Never turn the main switch to "OFF", "LOCK" or "OPEN" while the vehicle is moving. Otherwise the elec-

Smart key system

trical systems will be switched off, which may result in loss of control or an accident.


TIP

Do not push the main switch knob repeatedly or turn the main switch back and forth beyond normal use. Otherwise, to protect the main switch from damage, the smart key system will temporarily disable and the smart key system indicator light will flash. If this occurs, wait until the indicator light stops flashing before operating the main switch again.

The main switch positions are described below.

ON (on)

EAU76500



1. Push.
2. Turn.

All electrical circuits are supplied with the power, and the engine can be started.

To turn the vehicle power on

1. Turn the smart key on and bring it within operating range.


2. Push the main switch knob and the smart key indicator light will come on for approximately 4 seconds.
3. While the smart key system indicator light is on, turn the main switch to "ON". All of the turn signal lights flash twice and the vehicle power turns on.

TIP

- If the vehicle battery voltage is low, the turn signal lights will not flash.
- See "Emergency mode" on page 8-38 for information on turning the vehicle power on without the smart key.

OFF (off)

EAU76510



1. Turn.

All electrical systems are off.

To turn the vehicle power off


1. With the smart key turned on and within operating range, turn the main switch to "OFF".
2. The turn signal lights flash once and the vehicle power turns off.

TIP

When the main switch is turned to "OFF" but the smart key cannot be confirmed (the smart key is either outside operation range or has been turned off), the beeper will sound for 3 seconds and the smart key system indicator light will flash for 30 seconds.

- During this 30 seconds, the main switch can be freely operated.
- After 30 seconds, the vehicle power will turn off automatically.
- To turn the vehicle power off immediately, push the main switch knob four times within 2 seconds.

2. While the smart key system indicator light is on, turn the main switch to "OPEN".
3. To open the seat, push the "SEAT" button, and then lift the rear of the seat.




"SEAT" button

OPEN (open)


EAU79042

Power is supplied to the main switch. The seat and storage compartment A can be opened.


To open the seat and storage compartment A



4. To open storage compartment A, push the "LID" button.




1. Push.
2. Turn.



1. "LID" button

1. With the smart key turned on and within operating range, push the main switch knob.

Smart key system



1. Storage compartment A

TIP

Make sure that the seat and storage compartment are securely closed before starting off.

Open position reminder

To prevent you from accidentally leaving the vehicle unlocked by walking away with the main switch still in the "OPEN" position, the smart key system beeper will sound under the following conditions.

- When the main switch has been in the "OPEN" position for 3 minutes
- If the smart key is turned off while the main switch is in the "OPEN" position
- If you walk out of range of the smart key system with the main switch in the "OPEN" position

If the beeper sounds after 3 minutes, turn the main switch to "OFF" or "LOCK".

If the beeper sounds because the smart key was turned off or moved out of range, turn the smart key on and walk back into range.

TIP

- The beeper will turn off after 1 minute.

- The seat can also be opened with the mechanical key. (See page 5-20.)


EAU76521

"LOCK" (lock)

1



2



1. Push.
2. Push and turn.

The steering is locked and all electrical systems are off.


To lock the steering

1. Turn the handlebar all the way to the left.
2. With the smart key turned on and within operating range, push the main switch knob.
3. While the smart key system indicator light is on, push and turn the main switch to "LOCK".

TIP

If the steering will not lock, try turning the handlebar back to the right slightly.

To unlock the steering



1. Push.
2. Push and turn.

1. With the smart key turned on and within operating range, push the main switch knob.
2. While the smart key system indicator light is on, push and turn the main switch to the desired position.

To close the fuel tank cap lid

Push the fuel tank cap lid down until it is closed.


TIP

Make sure that fuel tank cap lid is securely closed before starting off.


EAU79000

“” (fuel tank cap lid)

To open the fuel tank cap lid




1. Push.
2. Turn.

1. With the smart key turned on and within operating range, push the main switch knob.
2. While the smart key system indicator light is on, turn the main switch to “”.

Instrument and control functions

Indicator lights and warning lights



1. Left turn signal indicator light "↶"
2. Right turn signal indicator light "↷"
3. High beam indicator light "≡"
4. Anti-lock Brake System (ABS) warning light "⊗"
5. Engine trouble warning light "🔧"
6. Traction control system indicator light "TCS"
7. Smart key system indicator light "🔑"

Turn signal indicator lights "↶" and "↷"

Each indicator light will flash when its corresponding turn signal lights are flashing.

High beam indicator light "≡"

This indicator light comes on when the high beam of the headlight is switched on.

Engine trouble warning light "🔧"

This warning light comes on if a problem is detected in the engine or other vehicle control system. If this occurs, have a Yamaha dealer check the on-board diagnostic system.

The electrical circuit of the warning light can be checked by turning the main switch to "ON". The warning light should come on for a few seconds, and then go off.

If the warning light does not come on initially when the main switch is turned to "ON", or if the warning light remains on, have a Yamaha dealer check the vehicle.

ABS warning light "⊗"

In normal operation, the ABS warning light comes on when the main switch is turned to "ON" and goes off after traveling at a speed of 10 km/h (6 mi/h) or higher.

If the ABS warning light:

- does not come on when the main switch is turned to "ON"
- comes on or flashes while riding
- does not go off after traveling at a speed of 10 km/h (6 mi/h) or higher

The ABS may not work correctly. If any of the above occurs, have a Yamaha dealer check the system as soon as possible. (See page 5-14 for an explanation of the ABS.)

WARNING

If the ABS warning light does not go off after traveling at a speed of 10 km/h (6 mi/h) or higher, or if the warning light comes on or flashes while riding, the brake system reverts to conventional braking. If either of the above occurs, or if the warning light does not come on at all, use extra caution to avoid possible wheel lock during emergency

braking. Have a Yamaha dealer check the brake system and electrical circuits as soon as possible.

TIP

The ABS warning light may come on while accelerating the engine with the vehicle on its centerstand, but this does not indicate a malfunction. If this happens, turn the main switch off and then back on again to reset the indicator light.

Traction control system indicator light "TCS"

This indicator light will flash when traction control has engaged. If the traction control system is turned off, this indicator light will come on. (See page 5-15.)


TIP

When the vehicle is turned on, the light should come on for a few seconds and then go off. If the light does not come on, or if the light remains on, have a Yamaha dealer check vehicle.

Smart key system indicator light "SK"

This indicator light communicates the status of the smart key system. When the smart key system is operating normally, this indicator light will be off. If there is an error in the smart key system, the indicator light will flash. The indicator light will also flash when communication between the vehicle and smart key takes place and when certain smart key system operations are carried out.

Speedometer



1. Speedometer

The speedometer shows the vehicle's traveling speed.

When the vehicle power is turned on, the speedometer needle will sweep once across the speed range and then return to zero in order to test the electrical circuit.

Instrument and control functions

Tachometer



1. Tachometer
2. Tachometer red zone

The electric tachometer allows the rider to monitor the engine speed and keep it within the ideal power range.

When the vehicle power is turned on, the tachometer needle will sweep once across the r/min range and then return to zero r/min in order to test the electrical circuit.

ECA10032

NOTICE

Do not operate the engine in the tachometer red zone.

Red zone: 9000 r/min and above

Multi-function display



1. Fuel meter
2. Information display
3. Coolant temperature meter
4. Clock
5. Tripmeter display
6. Icy road warning indicator "❄"




WARNING

Be sure to stop the vehicle before making any setting changes to the multi-function meter unit. Changing settings while riding can distract the operator and increase the risk of an accident.

The "TRIP/INFO" switch is located on the right side of the handlebar. This switch allows you to control or change the settings of the multi-function meter unit. To use the "TRIP" switch, move the "TRIP/INFO" switch in direction (a). To use the "INFO" switch, move the "TRIP/INFO" switch in direction (b).

Instrument and control functions



1. "TRIP/INFO" switch

The multi-function display is equipped with the following:

- clock
- fuel meter
- coolant temperature meter
- tripmeter display
- information display

TIP

To switch the displays between kilometers and miles, turn the main switch to "ON" while pushing the "INFO" switch, and then continue to push the "INFO" switch for eight seconds.

Clock



1. Clock


The clock uses a 24-hour time system.

To set the clock

1. Turn the main switch to "OFF".
2. Push and hold the "TRIP" switch.

3. Turn the main switch to "ON" while pushing the "TRIP" switch, and then continue to push the "TRIP" switch for eight seconds. The hour digits will start flashing.
4. Use the "TRIP" switch to set the hours.
5. Push the "TRIP" switch for three seconds, and then release it. The minute digits will start flashing.
6. Use the "TRIP" switch to set the minutes.
7. Push the "TRIP" switch for three seconds, and then release it to start the clock.

Fuel meter



1. Fuel meter

The fuel meter indicates the amount of fuel in the fuel tank. The segments of the fuel meter disappear from "F" (full) towards "E" (empty) as the fuel level decreases. When the last segment of the fuel meter starts flashing, refuel as soon as possible.


TIP

- If a problem is detected in the fuel meter, the all segments will flash repeatedly. If this occurs, have a Yamaha dealer check the vehicle.

Instrument and control functions

- When approximately 2.4 L (0.63 US gal, 0.53 Imp.gal) of fuel remains in the fuel tank, the last segment of the fuel meter will start flashing. The display will automatically change to the fuel reserve tripmeter "F Trip" and start counting the distance traveled from that point.

Coolant temperature meter



1. Coolant temperature meter

The coolant temperature meter indicates the temperature of the coolant. If the top segment flashes, stop the vehicle, then stop the engine, and let the engine cool. (See page 8-37.)

ECA10022

NOTICE

Do not continue to operate the engine if it is overheating.

TIP

- If a problem is detected in the coolant temperature meter, all segments will flash repeatedly. If this occurs, have a Yamaha dealer check the vehicle as soon as possible.
- The coolant temperature varies with changes in the weather and engine load.

Tripmeter display



1. Tripmeter display

The tripmeter display is equipped with the following:

- odometer
- tripmeter
- time tripmeter
- fuel reserve tripmeter
- oil change tripmeter
- V-belt replacement tripmeter

Push the "TRIP" switch to change the display between the odometer "Odo", tripmeter "Trip", time tripmeter "Trip Time", oil change tripmeter "Oil Trip", and V-belt replacement tripmeter "V-Belt Trip" in the following order:

Odo → Trip → Trip Time → Oil Trip → V-Belt Trip → Odo

Odometer "Odo" and tripmeter "Trip"

The odometer shows the total distance traveled by the vehicle.

The tripmeter shows the distance traveled since it was last reset.

To reset the tripmeter, select it by pushing the "TRIP" switch, and then push the "TRIP" switch for three seconds.

TIP

- The odometer will lock at 999999.

Instrument and control functions

- The tripmeter will reset and continue counting after 9999.9 is reached.

Time tripmeter "Time"



1. Time tripmeter


The time tripmeter displays the time that has elapsed while the main switch was in the "ON" position since it was last reset.

The maximum time that can be shown is 99:59.

TIP

To reset the time tripmeter, select it by pushing the "TRIP" switch, and then push the "TRIP" switch for three seconds.

Fuel reserve tripmeter "F Trip"



1. Fuel reserve tripmeter


When approximately 2.4 L (0.63 US gal, 0.53 Imp.gal) of fuel remains in the fuel tank, the last segment of the fuel meter will start flashing. The display will automatically change to the fuel reserve tripmeter "F Trip" and start counting the distance traveled from that point. In this case, push the "TRIP" switch to switch the display in the following order:

F Trip → Oil Trip → V-Belt Trip → Odo → Trip → Trip Time → F Trip

To reset the fuel reserve tripmeter, select it by pushing the "TRIP" switch, and then push the "TRIP" switch for three seconds.

The fuel reserve tripmeter will reset automatically and disappear after refueling and traveling 5 km (3 mi).

Oil change tripmeter "Oil Trip"



1. Oil change indicator "OIL"

2. Oil change tripmeter

The oil change tripmeter shows the distance traveled since the oil was last changed.

The oil change indicator "OIL" flashes at the initial 1000 km (600 mi), then at 4000 km (2400 mi) and every 5000 km (3000 mi) thereafter to indicate that the engine oil should be changed.

Instrument and control functions

After changing the engine oil, reset the oil change indicator and the oil change tripmeter. To reset them both, select the oil change tripmeter, and then push the "TRIP" switch for three seconds. While the oil change tripmeter is flashing, push the "TRIP" switch for 15 to 20 seconds. Release the "TRIP" switch, and the oil trip value will reset to zero.

TIP

If the engine oil is changed before the oil change indicator comes on (i.e., before the periodic oil change interval has been reached), the oil change tripmeter must be reset for the oil change indicator to come on at the correct time.

V-belt replacement tripmeter "V-Belt Trip"



1. V-belt replacement indicator "V-Belt"
2. V-belt replacement tripmeter

The V-belt replacement tripmeter shows the distance traveled since the V-belt was last replaced.

The V-belt replacement indicator "V-Belt" will flash every 20000 km (12000 mi) to indicate that the V-belt should be replaced.


After replacing the V-belt, reset the V-belt replacement indicator and the V-belt replacement tripmeter. To reset

them both, select the V-belt replacement tripmeter, and then push the "TRIP" switch for three seconds. While the V-belt replacement tripmeter is flashing, push the "TRIP" switch for 15 to 20 seconds. Release the "TRIP" switch, and the V-belt trip value will reset to zero.

TIP

If the V-belt is replaced before the V-belt replacement indicator comes on (i.e., before the periodic V-belt replacement interval has been reached), the V-belt replacement tripmeter must be reset for the V-belt replacement indicator to come on at the correct time.

Information display



1. Information display

The information display is equipped with the following:

- air temperature display
- battery voltage display
- traction control system display
- average fuel consumption display
- instantaneous fuel consumption display
- average speed display
- warning message function

Instrument and control functions

Navigating the information display

Push the "INFO" switch to change the display between the air temperature display "Air-temp", battery voltage display "Battery", traction control system display "TCS ON" or "TCSOFF", average fuel consumption display "Consumption/Average_ _ _ km/L", "Consumption/Average_ _ _ L/100 km" or "Consumption/Average_ _ _ MPG", instantaneous fuel consumption display "Consumption_ _ _ km/L", "Consumption_ _ _ L/100 km" or "Consumption_ _ _ MPG" and average speed display "Average" in the following order:

Air-temp → Battery → TCS ON or TCSOFF → Consumption/Average_ _ _ km/L → Consumption/Average_ _ _ L/100 km → Consumption/Average_ _ _ MPG → Consumption_ _ _ km/L → Consumption_ _ _ L/100 km → Consumption_ _ _ MPG → Average → Air-temp

TIP

- When kilometers are selected for the display units, "Consumption/Average_ _ _ MPG" and "Consumption_ _ _ MPG" are not displayed.
- When miles are selected for the display units, "Consumption/Average_ _ _ km/L", "Consumption/Average_ _ _ L/100 km", "Consumption_ _ _ km/L", and "Consumption_ _ _ L/100 km" are not displayed.

Air temperature display



1. Air temperature display
2. Icy road warning indicator "❄"

This display shows the air temperature from 14 °F to 122 °F in 1 °F increments. The icy road warning indicator "❄" will flash when the temperature is below 38 °F.

The temperature displayed may vary from the actual ambient temperature.

TIP

The accuracy of the temperature reading may be affected by engine heat when riding slowly (under 20 km/h [12 mi/h]) or when stopped at traffic signals, etc.

Battery voltage display



1. Battery voltage display

This display shows the current charge state of the battery.

Instrument and control functions

TIP

- If the engine turns over slowly when using the start switch, have a Yamaha dealer charge the battery.
- If “---” appears in the battery voltage display, have a Yamaha dealer check the battery.

Traction control system display



1. Traction control system display


This display shows the current status of the traction control system. (See page 5-15.)

- “TCS ON”: the system is on
- “TCSOFF”: the system is off

TIP

If only “TCS” is displayed, there is a communication error within the vehicle. Have a Yamaha dealer check the vehicle as soon as possible.

Average fuel consumption display



1. Average fuel consumption display

This function calculates the average fuel consumption since it was last reset.

The average fuel consumption can be displayed as either “Consumption/Average_ _ _ km/L”, “Consumption/Average_ _ _ L/100 km” or “Consumption/Average_ _ _ MPG”.

- “Consumption/Average_ _ _ km/L”: The average distance that can be traveled on 1.0 L of fuel is shown.
- “Consumption/Average_ _ _ L/100 km”: The average amount of fuel necessary to travel 100 km is shown.
- “Consumption/Average_ _ _ MPG”: The average distance that can be traveled on 1.0 US.gal of fuel is shown.

To reset the average fuel consumption, push the “INFO” switch for at least three seconds.

TIP

After resetting the average fuel consumption, “_ _ _” will be shown until the vehicle has traveled 1 km (0.6 mi).

Instrument and control functions

Instantaneous fuel consumption display



1. Instantaneous fuel consumption display

This function calculates the fuel consumption under current riding conditions.

The instantaneous fuel consumption can be displayed as either "Consumption_ _ _ km/L", "Consumption_ _ _ L/100 km" or "Consumption_ _ _ MPG".

- "Consumption_ _ _ km/L": The distance that can be traveled on 1.0 L of fuel under the current riding conditions is shown.
- "Consumption_ _ _ L/100 km": The amount of fuel necessary to travel 100 km under the current riding conditions is shown.
- "Consumption_ _ _ MPG": The distance that can be traveled on 1.0 US.gal of fuel under the current riding conditions is shown.

TIP

If traveling at speeds under 10 km/h (6 mi/h), " _ _ _ " is displayed.

Average speed display



1. Average speed display

The average speed "Average_ _ _ kmh" or "Average_ _ _ MPH" is displayed.

The average speed is the total distance divided by the total time (with the main switch in the "ON" position) since the display was last reset to zero.

This display shows the average speed since it was last reset.

To reset the average speed display, select it by pushing the "INFO" switch, and then push the "INFO" switch for three seconds.

Warning message function

This function displays a warning message corresponding to the current warning.

"L FUEL": Appears when the last segment of the fuel meter starts flashing. If "L FUEL" is displayed, refuel as soon as possible.

"H TEMP": Appears when the top segment of the coolant temperature meter starts flashing. If "H TEMP" is displayed, stop the vehicle, then stop the engine, and let the engine cool.

"ICE": Appears when the icy road warning indicator "⚠" starts flashing. If "ICE" is displayed, be careful of icy roads.

Instrument and control functions

EAU1234M

"OIL SERV": Appears when the oil change indicator "OIL" starts flashing. If "OIL SERV" is displayed, change the engine oil, and then reset the oil change indicator and oil change tripmeter.

"V-BELT SERV": Appears when the V-belt replacement indicator "V-Belt" starts flashing. If "V-BELT SERV" is displayed, replace the V-belt, and then reset the V-belt replacement indicator and V-belt replacement tripmeter.


When there are two or more warnings, the warning messages are displayed in the following order:

5

L FUEL → H TEMP → ICE → OIL SERV
→ VBELT SERV → L FUEL


Handlebar switches

Left



1. Dimmer/Pass switch "HI/LO/PASS"
2. Turn signal switch "↵/↶"
3. Horn switch "🔊"

Right



1. Stop/Run/Start switch "STOP/RUN/START"
2. Hazard switch "⚠"
3. "TRIP/INFO" switch

Dimmer/Pass switch "HI/LO/PASS"

EAU54201

Set this switch to "HI" for the high beam and to "LO" for the low beam.

To flash the high beam, push the pass side "PASS" of the switch while the headlights are on low beam.

Turn signal switch "↵/↶"

EAU12461

To signal a right-hand turn, push this switch to "↶". To signal a left-hand turn, push this switch to "↵". When released, the switch returns to the cen-



Instrument and control functions


ter position. To cancel the turn signal lights, push the switch in after it has returned to the center position.

Horn switch “”

Press this switch to sound the horn.

Stop/Run/Start switch “//”

To crank the engine with the starter, set this switch to “”, and then push the switch down towards “”. See page 7-2 for starting instructions prior to starting the engine.

Set this switch to “” to stop the engine in case of an emergency, such as when the vehicle overturns or when the throttle cable is stuck.

Hazard switch “”

With the main switch in the “ON” position, use this switch to turn on the hazard lights (simultaneous flashing of all turn signal lights).

The hazard lights are used in case of an emergency or to warn other drivers when your vehicle is stopped where it might be a traffic hazard.


NOTICE

Do not use the hazard lights for an extended length of time with the engine not running, otherwise the battery may discharge.

“TRIP/INFO” switch

This switch is used to make setting and display changes in the multi-function meter unit. See page 5-3 for more information.

To use the “TRIP” switch, move the “TRIP/INFO” switch in direction (a). To use the “INFO” switch, move the “TRIP/INFO” switch in direction (b).




1. “TRIP/INFO” switch

Instrument and control functions

EAU12952

EAU12952


Front brake lever



1. Front brake lever

The front brake lever is located on the right side of the handlebar. To apply the front brake, pull this lever toward the throttle grip.

Rear brake lever



1. Rear brake lever

The rear brake lever is located on the left side of the handlebar. To apply the rear brake, pull this lever toward the handlebar grip.

EAU78200

ABS

The Yamaha ABS (Anti-lock Brake System) features a dual electronic control system, which acts on the front and rear brakes independently.

Operate the brakes with ABS as you would conventional brakes. If the ABS is activated, a pulsating sensation may be felt at the brake levers. In this situation, continue to apply the brakes and let the ABS work; do not "pump" the brakes as this will reduce braking effectiveness.

EWA16051

ECA20100

- This ABS has a test mode which allows the owner to experience the pulsation at the brake levers when the ABS is operating. However, special tools are required, so please consult your Yamaha dealer.

NOTICE

Be careful not to damage the wheel sensor or wheel sensor rotor; otherwise, improper performance of the ABS will result.

WARNING


Always keep a sufficient distance from the vehicle ahead to match the riding speed even with ABS.

- The ABS performs best with long braking distances.
- On certain surfaces, such as rough or gravel roads, the braking distance may be longer with the ABS than without.


The ABS is monitored by an ECU, which will revert the system to conventional braking if a malfunction occurs.

TIP

- The ABS performs a self-diagnosis test each time the vehicle first starts off after the main switch is turned to "ON" and the vehicle has traveled at a speed of 10 km/h (6 mi/h) or higher. During this test, a "clicking" noise can be heard from the front of the vehicle, and if either brake lever is even slightly applied, a vibration can be felt at the lever, but these do not indicate a malfunction.



1. Front wheel sensor
2. Front wheel sensor rotor



1. Rear wheel sensor
2. Rear wheel sensor rotor

Instrument and control functions


Traction control system

The traction control system (TCS) helps maintain traction when accelerating on slippery surfaces, such as unpaved or wet roads. If sensors detect that the rear wheel is starting to slip (uncontrolled spinning), the traction control system assists by regulating engine power until traction is restored. When traction control has engaged, the "TCS" indicator light will flash. You may notice changes in engine response or exhaust sound.

WARNING

The traction control system is not a substitute for riding appropriately for the conditions. Traction control cannot prevent loss of traction due to excessive speed when entering turns, when accelerating hard at a sharp lean angle, or while braking, and cannot prevent front wheel slipping. As with any vehicle, approach surfaces that may be slippery with caution and avoid especially slippery surfaces.


Setting the traction control system



1. Traction control system indicator light "TCS"
2. Traction control system display

When the vehicle is turned on, traction control is automatically turned on.

To turn the traction control system off, use the "INFO" switch to change the information display to the traction control system display. Then push the "INFO" switch for three seconds. The display will show "TCSOFF", and the "TCS" indicator light will come on.



1. Traction control system indicator light "TCS"
2. Traction control system display

TIP

Turn the traction control system off to help free the rear wheel if the vehicle gets stuck in mud, sand, or other soft surfaces.


NOTICE

Use only the specified tires. (See page 8-19.) Using different sized tires will prevent the traction control system from controlling tire rotation accurately.

Resetting the traction control system

The traction control system will automatically disable under certain conditions; such as when a sensor fault is detected, or when only one wheel is allowed to rotate for more than a few

seconds. Should this happen, the "TCS" indicator light will come on, and possibly the "⚠" warning light, too.



1. Traction control system indicator light "TCS"
2. Engine trouble warning light "⚠"

TIP

When the vehicle is on the centerstand, do not rev the engine for an extended period of time. Otherwise, the traction control system will automatically disable and need to be reset.

If the traction control system automatically disables, try resetting it as follows.

1. Stop the vehicle and turn it off completely.
2. Wait a few seconds and then turn the vehicle power on.
3. The "TCS" indicator light should turn off and the system be enabled.

TIP


If the "TCS" indicator light remains on after resetting, the vehicle may still be ridden; however, have a Yamaha dealer check the vehicle as soon as possible.

4. Have a Yamaha dealer check the vehicle and turn off the "⚠" warning light.

Fuel tank cap


To remove the fuel tank cap

1. Turn the main switch to "I" to open the fuel tank cap lid.



1. Fuel tank cap lid

2. Turn the fuel tank cap counter-clockwise until the release mark "o" aligns with "▽" and then pull the cap off.



1. Fuel tank cap
2. Release mark "o"


To install the fuel tank cap

1. Insert the fuel tank cap onto the tank opening and turn it clockwise until the install mark "△" aligns with "▽".

Instrument and control functions

EAU13213

EW10882



1. Install mark "△"

2. Close the fuel tank cap lid.

EW11052

WARNING

Make sure that the fuel tank cap is properly closed after filling fuel. Leaking fuel is a fire hazard.


Fuel

Make sure there is sufficient gasoline in the tank.

WARNING

Gasoline and gasoline vapors are extremely flammable. To avoid fires and explosions and to reduce the risk of injury when refueling, follow these instructions.

1. Before refueling, turn off the engine and be sure that no one is sitting on the vehicle. Never refuel while smoking, or while in the vicinity of sparks, open flames, or other sources of ignition such as the pilot lights of water heaters and clothes dryers.
2. Do not overfill the fuel tank. Stop filling when the fuel reaches the bottom of the filler tube. Because fuel expands when it heats up, heat from the engine or the sun can cause fuel to spill out of the fuel tank.



1. Fuel tank filler tube

2. Maximum fuel level

3. Wipe up any spilled fuel immediately. **NOTICE: Immediately wipe off spilled fuel with a clean,**

dry, soft cloth, since fuel may deteriorate painted surfaces or plastic parts. [ECA10072]

4. Be sure to securely close the fuel tank cap.

EWA15152

WARNING

Gasoline is poisonous and can cause injury or death. Handle gasoline with care. Never siphon gasoline by mouth. If you should swallow some gasoline or inhale a lot of gasoline vapor, or get some gasoline in your eyes, see your doctor immediately. If gasoline spills on your skin, wash with soap and water. If gasoline spills on your clothing, change your clothes.

EAU36085

Recommended fuel

Regular unleaded gasoline (Gasohol [E10] acceptable)

Fuel tank capacity:

13 L (3.4 US gal, 2.9 Imp.gal)

ECA11401

NOTICE

Use only unleaded gasoline. The use of leaded gasoline will cause severe damage to internal engine parts, such as the valves and piston rings, as well as to the exhaust system.

Your Yamaha engine has been designed to use unleaded gasoline with a pump octane number $[(R+M)/2]$ of 86 or higher, or a research octane number of 91 or higher. If knocking (or pinging) occurs, use a gasoline of a different


brand or premium unleaded fuel. Use of unleaded fuel will extend spark plug life and reduce maintenance costs.

Gasohol

There are two types of gasohol: gasohol containing ethanol and that containing methanol. Gasohol containing ethanol can be used if the ethanol content does not exceed 10% (E10). Gasohol containing methanol is not recommended by Yamaha because it can cause damage to the fuel system or vehicle performance problems.

Instrument and control functions

Fuel tank overflow hose



1. Fuel tank overflow hose

Before operating the vehicle:

- Check the fuel tank overflow hose connection.
- Check the fuel tank overflow hose for cracks or damage, and replace it if necessary.
- Make sure that the end of the fuel tank overflow hose is not blocked, and clean it if necessary.
- Make sure that the end of the fuel tank overflow hose is positioned as shown.

TIP

See page 8-9 for canister information.

Catalytic converters

This vehicle is equipped with catalytic converters in the exhaust system.

WARNING

The exhaust system is hot after operation. To prevent a fire hazard or burns:


- Do not park the vehicle near possible fire hazards such as grass or other materials that easily burn.
- Park the vehicle in a place where pedestrians or children are not likely to touch the hot exhaust system.
- Make sure that the exhaust system has cooled down before doing any maintenance work.
- Do not allow the engine to idle more than a few minutes. Long idling can cause a build-up of heat.

NOTICE


Use only unleaded gasoline. The use of leaded gasoline will cause unreparable damage to the catalytic converter.

Storage compartments

This model is equipped with 3 storage compartments. The front storage compartments and rear storage compartment are located as shown.



1. Storage compartment A
2. Storage compartment B



1. Rear storage compartment

TIP

- Storage compartment A must be opened using the smart key system. (See page 4-10.)
- The seat/rear storage compartment can be opened using the smart key system or the mechanical key.
- Some helmets cannot be stored in the rear storage compartment because of their size or shape.


Storage compartment A

To open storage compartment A, turn the main switch to "OPEN" and then push the "LID" button.

To close storage compartment A, push the storage compartment lid until it is closed.

Storage compartment B

To open storage compartment B, push the storage compartment lid inward to unlock it, and then pull to open.



1. Lid
2. Storage compartment

To close storage compartment B, push the storage compartment lid into the original position.

Seat/rear storage compartment


To open the seat/rear storage compartment via the main switch

Turn the main switch to "OPEN", and then push the "SEAT" button.

To open the seat/rear storage compartment with the mechanical key


1. Open the keyhole cover.

Instrument and control functions



1. Keyhole cover

2. Insert the mechanical key into the seat lock, and then turn it clockwise.



1. Seat lock
2. Unlock.

TIP

Be sure to close the seat and all storage compartments before starting off.

ECA24020

NOTICE

Make sure that the keyhole cover is installed when the mechanical key is not being used.

ECA21150

NOTICE

Keep the following points in mind when using the storage compartment.

- Since the storage compartment accumulates heat when exposed to the sun and/or the engine heat, do not store anything susceptible to heat, consumables or flammable items inside it.
- To avoid humidity from spreading through the storage compartment, wrap wet articles in a plastic bag before storing them in the compartment.
- Since the storage compartment may get wet while the vehicle is being washed, wrap any articles stored in the compartment in a plastic bag.
- Do not keep anything valuable or breakable in the storage compartment.

EWA18950




WARNING

- Do not exceed the load limit of 1 kg (2 lb) for storage compartment A.
- Do not exceed the load limit of 0.5 kg (1.1 lb) for storage compartment B.
- Do not exceed the load limit of 5 kg (11 lb) for the rear storage compartment.
- Do not exceed the maximum load of 161 kg (355 lb) for the vehicle.

Windshield


To suit the rider's preference, the windshield height can be changed to one of two positions.



1. Windshield


To change the windshield height to the high position

1. Remove the bolt access covers by removing the quick fasteners.




1. Quick fastener
2. Bolt access cover

2. Remove the windshield by removing the bolts.




1. Bolt

3. Remove the bolts, and then install the bolts in the desired position.



1. Bolt




1. Bolt

4. Install the windshield to the high position by installing the bolts, and then tighten the bolts to the specified torque. **WARNING! A loose windshield could cause an accident. Be sure to tighten the screws to the specified torque.**

[EWA15511]

Instrument and control functions




1. Bolt

Tightening torque:

Windshield bolt:

8 N·m (0.8 kgf·m, 5.9 lb·ft)


5. Place the bolt access covers, and then install the quick fasteners.




1. Bolt access cover

To change the windshield height to the low position

1. Remove the bolt access covers by removing the quick fasteners.
2. Remove the windshield by removing the bolts.
3. Remove the bolts, and then install the bolts in the desired position.




1. Bolt



1. Bolt

4. Install the windshield to the low position by installing the bolts, and then tighten the bolts to the specified torque. **WARNING! A loose windshield could cause an accident. Be sure to tighten the screws to the specified torque.**

[EWA15511]



1. Bolt

Instrument and control functions

EAU46833


Tightening torque:

Windshield bolt:
8 N·m (0.8 kgf·m, 5.9 lb·ft)

5. Place the bolt access covers, and then install the quick fasteners.

Handlebar position

The handlebar can be adjusted to one of two positions to suit the rider's preference. Have a Yamaha dealer adjust the position of the handlebar.



1. Handlebar

5

Instrument and control functions

Adjusting the shock absorber assemblies

EAU14894

EWA10211

WARNING

Always adjust both shock absorber assemblies equally, otherwise poor handling and loss of stability may result.

Each shock absorber assembly is equipped with a spring preload adjusting ring.


ECA10102

NOTICE

To avoid damaging the mechanism, do not attempt to turn beyond the maximum or minimum settings.

Adjust the spring preload as follows. To increase the spring preload and thereby harden the suspension, turn the adjusting ring on each shock absorber assembly in direction (a). To decrease the spring preload and thereby soften the suspension, turn the adjusting ring on each shock absorber assembly in direction (b).

- Align the appropriate notch in the adjusting ring with the position indicator on the shock absorber.
- Use the spring preload adjusting tool included in the owner's tool kit to make this adjustment.



1. Spring preload adjusting ring
2. Special wrench
3. Position indicator

Spring preload setting:

Minimum (soft):

1

Standard:

3

Maximum (hard):

5

EAU15306

EAU78690

Sidestand

The sidestand is located on the left side of the frame. Raise the sidestand or lower it with your foot while holding the vehicle upright.

TIP

The built-in sidestand switch is part of the ignition circuit cut-off system, which cuts the ignition in certain situations. (See the following section for an explanation of the ignition circuit cut-off system.)

EWA10242



WARNING

The vehicle must not be ridden with the sidestand down, or if the sidestand cannot be properly moved up (or does not stay up), otherwise the sidestand could contact the ground and distract the operator, resulting in a possible loss of control. Yamaha's ignition circuit cut-off system has been designed to assist the operator in fulfilling the responsibility of raising the sidestand before starting off. Therefore, check this system regularly and have a Yamaha dealer repair it if it does not function properly.

Ignition circuit cut-off system

The ignition circuit cut-off system works with the sidestand switch and brake light switches. It has the following functions.

- It prevents the engine from starting when the sidestand is down.
- It prevents the engine from starting if the brakes are not applied.
- It will stop the running engine if the sidestand is moved down.

Periodically check the operation of the ignition circuit cut-off system according to the following procedure.

Instrument and control functions

With the engine turned off:
1. Move the sidestand down.
2. Turn the main switch on.
3. Keep the front or rear brake applied.
4. Push the start switch.
Does the engine start?



WARNING

- **The vehicle must be placed on the centerstand during this inspection.**
- **If a malfunction is noted, have a Yamaha dealer check the system before riding.**

NO

YES

The sidestand switch may not be working correctly.

The vehicle should not be ridden until checked by a Yamaha dealer.

5
With the engine still off:
5. Move the sidestand up.
6. Keep the front or rear brake applied.
7. Push the start switch.
Does the engine start?

YES

NO

The brake switch may not be working correctly.

The vehicle should not be ridden until checked by a Yamaha dealer.

With the engine still running:
8. Move the sidestand down.
Does the engine stall?

YES

NO

The sidestand switch may not be working correctly.

The vehicle should not be ridden until checked by a Yamaha dealer.

The system is OK. **The vehicle can be ridden.**

Instrument and control functions

Auxiliary DC jack

EAU78213

EWA14361

WARNING

To prevent electrical shock or short-circuiting, make sure that the cap is installed when the auxiliary DC jack is not being used.

EGA15432

NOTICE


The accessory connected to the auxiliary DC jack should not be used with the engine turned off, and the load must never exceed 12 W (1 A), otherwise the fuse may blow or the battery may discharge.

This vehicle is equipped with an auxiliary DC jack located within storage compartment A.

A 12-V accessory connected to the auxiliary DC jack can be used when the main switch is in the "ON" position and should only be used when the engine is running.

To use the auxiliary DC jack


1. Open storage compartment A.
(See page 4-10.)
2. Turn the main switch off.
3. Remove the auxiliary DC jack cap.



1. Auxiliary DC jack cap

4. Turn the accessory off.

5. Insert the accessory plug into the auxiliary DC jack.



1. Auxiliary DC jack

6. Turn the main switch on, and then start the engine. (See page 7-2.)
7. Turn the accessory on.

For your safety – pre-operation checks

EAU53440

Inspect your vehicle each time you use it to make sure the vehicle is in safe operating condition. Always follow the inspection and maintenance procedures and schedules described in the Owner's Manual.

EWA11152

WARNING

Failure to inspect or maintain the vehicle properly increases the possibility of an accident or equipment damage. Do not operate the vehicle if you find any problem. If a problem cannot be corrected by the procedures provided in this manual, have the vehicle inspected by a Yamaha dealer.

Before using this vehicle, check the following points:

ITEM	CHECKS	PAGE
Fuel	<ul style="list-style-type: none">• Check fuel level in fuel tank.• Refuel if necessary.• Check fuel line for leakage.• Check fuel tank overflow hose for obstructions, cracks or damage, and check hose connection.	5-17, 5-19
Engine oil	<ul style="list-style-type: none">• Check oil level in engine.• If necessary, add recommended oil to specified level.• Check vehicle for oil leakage.	8-9
Final transmission oil	<ul style="list-style-type: none">• Check vehicle for oil leakage.	8-12
Coolant	<ul style="list-style-type: none">• Check coolant level in reservoir.• If necessary, add recommended coolant to specified level.• Check cooling system for leakage.	8-13
Front brake	<ul style="list-style-type: none">• Check operation.• If soft or spongy, have Yamaha dealer bleed hydraulic system.• Check brake pads for wear.• Replace if necessary.• Check fluid level in reservoir.• If necessary, add specified brake fluid to specified level.• Check hydraulic system for leakage.	8-22, 8-23, 8-23
Rear brake	<ul style="list-style-type: none">• Check operation.• If soft or spongy, have Yamaha dealer bleed hydraulic system.• Check brake pads for wear.• Replace if necessary.• Check fluid level in reservoir.• If necessary, add specified brake fluid to specified level.• Check hydraulic system for leakage.	8-22, 8-23, 8-23
Throttle grip	<ul style="list-style-type: none">• Make sure that operation is smooth.• Check throttle grip free play.• If necessary, have Yamaha dealer adjust throttle grip free play and lubricate cable and grip housing.	8-18, 8-26

For your safety – pre-operation checks

ITEM	CHECKS	PAGE
Control cables	<ul style="list-style-type: none"> • Make sure that operation is smooth. • Lubricate if necessary. 	8-25
Wheels and tires	<ul style="list-style-type: none"> • Check for damage. • Check tire condition and tread depth. • Check air pressure. • Correct if necessary. 	8-19, 8-21
Brake levers	<ul style="list-style-type: none"> • Make sure that operation is smooth. • Lubricate lever pivoting points if necessary. 	8-26
Centerstand, side-stand	<ul style="list-style-type: none"> • Make sure that operation is smooth. • Lubricate pivots if necessary. 	8-27
Chassis fasteners	<ul style="list-style-type: none"> • Make sure that all nuts, bolts and screws are properly tightened. • Tighten if necessary. 	—
Instruments, lights, signals and switches	<ul style="list-style-type: none"> • Check operation. • Correct if necessary. 	—
Sidestand switch	<ul style="list-style-type: none"> • Check operation of ignition circuit cut-off system. • If system is not working correctly, have Yamaha dealer check vehicle. 	5-26

Operation and important riding points

EAU15952

EAU78221

Read the Owner's Manual carefully to become familiar with all controls. If there is a control or function you do not understand, ask your Yamaha dealer.

8WA10272

WARNING

Failure to familiarize yourself with the controls can lead to loss of control, which could cause an accident or injury.

TIP

This model is equipped with a lean angle sensor to stop the engine in case of a turnover. In this case, the engine trouble warning light will come on but this is not a malfunction. Before restarting the engine, turn the main switch off and then back on to reset the engine trouble warning light. Failing to do so will prevent the engine from starting even though the engine will crank when pushing the start switch.

Operation and important riding points

Starting the engine

EAU78231

EGA10251

NOTICE

See page 7-5 for engine break-in instructions prior to operating the vehicle for the first time.

In order for the ignition circuit cut-off system to enable starting, the side-stand must be up. (See page 5-26.)

1. Turn the main switch on and make sure that the stop/run/start switch is set to "○".

The following warning lights and indicator lights should come on for a few seconds, then go off.

- Engine trouble warning light
- Traction control system indicator light
- Smart key system indicator light

TIP

The ABS warning light should come on and stay on until the vehicle reaches a traveling speed of 10 km/h (6 mi/h) or higher.

EGA22510

NOTICE

If a warning or indicator light does not work as described above, see page 5-1 for the corresponding warning and indicator light circuit check.

2. Close the throttle.
3. While applying the front or rear brake, push the "⊕" side of the stop/run/start switch. Release it when the engine starts.

TIP

If the engine does not start, release the start switch after 5 seconds. Before pressing the start switch again, wait 10 seconds to allow battery voltage to restore.

ECA11043

NOTICE

For maximum engine life, never accelerate hard when the engine is cold!


Operation and important riding points

EAU45093

EAU16782

Starting off

1. While pulling the rear brake lever with your left hand and holding the grab bar with your right hand, push the scooter off the center-stand.



1. Grab bar
2. Sit astride the seat, and then adjust the rear view mirrors.
3. Switch the turn signals on.
4. Check for oncoming traffic, and then slowly turn the throttle grip (on the right) in order to take off.
5. Switch the turn signals off.

Acceleration and deceleration



The speed can be adjusted by opening and closing the throttle. To increase the speed, turn the throttle grip in direction (a). To reduce the speed, turn the throttle grip in direction (b).

EAU16794

EAU16821

Braking

EWA10301



WARNING

- **Avoid braking hard or suddenly (especially when leaning over to one side), otherwise the scooter may skid or overturn.**
- **Railroad crossings, streetcar rails, iron plates on road construction sites, and manhole covers become extremely slippery when wet. Therefore, slow down when approaching such areas and cross them with caution.**
- **Keep in mind that braking on a wet road is much more difficult.**
- **Ride slowly down a hill, as braking downhill can be very difficult.**

1. Close the throttle completely.
2. Apply both front and rear brakes simultaneously while gradually increasing the pressure.

Tips for reducing fuel consumption

Fuel consumption depends largely on your riding style. Consider the following tips to reduce fuel consumption:

- Avoid high engine speeds during acceleration.
- Avoid high engine speeds with no load on the engine.
- Turn the engine off instead of letting it idle for an extended length of time (e.g., in traffic jams, at traffic lights or at railroad crossings).

Operation and important riding points

EAU16B42

EAU1421

Engine break-in

There is never a more important period in the life of your engine than the period between 0 and 1600 km (1000 mi). For this reason, you should read the following material carefully.

Since the engine is brand new, do not put an excessive load on it for the first 1600 km (1000 mi). The various parts in the engine wear and polish themselves to the correct operating clearances. During this period, prolonged full-throttle operation or any condition that might result in engine overheating must be avoided.

EAU34323

0–1000 km (0–600 mi)

Avoid prolonged operation above 4500 r/min. **NOTICE: After 1000 km (600 mi) of operation, be sure to replace the engine oil, final transmission oil and the oil filter element.** [ECA12932]

1000–1600 km (600–1000 mi)

Avoid prolonged operation above 5400 r/min.

1600 km (1000 mi) and beyond

The vehicle can now be operated normally.

ECA10311

NOTICE

- Keep the engine speed out of the tachometer red zone.
- If any engine trouble should occur during the engine break-in period, immediately have a Yamaha dealer check the vehicle.

Parking


When parking, turn the vehicle power off, and then turn the smart key off.

TIP

Even when the vehicle is parked in a location partitioned by a fence or the glass window of a shop, if the smart key is within operating range, other people will be able to start the engine and operate the vehicle. Please turn the smart key off when leaving the vehicle. (See page 4-6.)

If the sidestand is lowered when the engine is running, the engine will stop and the beeper will sound for approximately 1 minute. To stop the beeper, turn the vehicle power off or raise the sidestand.

TIP

- Before leaving the vehicle, be sure to turn the main switch to “OFF” or “”. Otherwise, the battery may discharge.
- The sidestand alarm beeper can be set to not activate. Please contact your Yamaha dealer.

EWA10312



WARNING

- Since the engine and exhaust system can become very hot, park in a place where pedestrians or children are not likely to touch them and be burned.
- Do not park on a slope or on soft ground, otherwise the vehicle may overturn, increasing the risk of a fuel leak and fire.

Operation and important riding points

- Do not park near grass or other flammable materials which might catch fire.
-

Periodic maintenance and adjustment

EAU17246

Periodic inspection, adjustment, and lubrication will keep your vehicle in the safest and most efficient condition possible. Safety is an obligation of the vehicle owner/operator. The most important points of vehicle inspection, adjustment, and lubrication are explained on the following pages.

The intervals given in the periodic maintenance charts should be simply considered as a general guide under normal riding conditions. However, depending on the weather, terrain, geographical location, and individual use, the maintenance intervals may need to be shortened.

EWA10322

WARNING

Failure to properly maintain the vehicle or performing maintenance activities incorrectly may increase your risk of injury or death during service or while using the vehicle. If you are not familiar with vehicle service, have a Yamaha dealer perform service.

EWA15123

WARNING

Turn off the engine when performing maintenance unless otherwise specified.

- A running engine has moving parts that can catch on body parts or clothing and electrical parts that can cause shocks or fires.
- Running the engine while servicing can lead to eye injury, burns, fire, or carbon monoxide poisoning – possibly leading to


death. See page 2-2 for more information about carbon monoxide.

EWA15461

WARNING

Brake discs, calipers, drums, and linings can become very hot during use. To avoid possible burns, let brake components cool before touching them.

Owner's tool kit



1. Owner's tool kit

Emission controls not only function to ensure cleaner air, but are also vital to proper engine operation and maximum performance. In the following periodic maintenance charts, the services related to emissions control are grouped separately. These services require specialized data, knowledge, and equipment. Maintenance, replacement, or repair of the emission control devices and systems may be performed by any repair establishment or individual that is certified (if applicable). Yamaha dealers are trained and equipped to perform these particular services.

The owner's tool kit is located on the bottom of the seat. (See page 4-10.)

The service information included in this manual and the tools provided in the owner's tool kit are intended to assist you in the performance of preventive maintenance and minor repairs. However, additional tools such as a torque wrench may be necessary to perform certain maintenance work correctly.

TIP

If you do not have the tools or experience required for a particular job, have a Yamaha dealer perform it for you.

Periodic maintenance and adjustment

EAU48491

TIP

- From 24000 mi (37000 km) or 36 months, repeat the maintenance intervals starting from 8000 mi (13000 km) or 12 months.
- Items marked with an asterisk require special tools, data and technical skills, have a Yamaha dealer perform the service.

EAU63292

Periodic maintenance chart for the emission control system

No.	ITEM	ROUTINE × 1000 mi × 1000 km month	INITIAL	ODOMETER READINGS					
			0.6	4	8	12	16	20	
			1	7	13	19	25	31	
			1	6	12	18	24	30	
1	* Fuel line	<ul style="list-style-type: none">• Check fuel hoses for cracks or damage.• Replace if necessary.		✓	✓	✓	✓	✓	
2	* Spark plug	<ul style="list-style-type: none">• Check condition.• Adjust gap and clean.		✓	✓	✓	✓	✓	
		<ul style="list-style-type: none">• Replace.	Every 12000 mi (19000 km)						
3	* Valve clearance	<ul style="list-style-type: none">• Check and adjust.	Every 12000 mi (19000 km)						
4	* Crankcase breather system	<ul style="list-style-type: none">• Check breather hose for cracks or damage.• Replace if necessary.		✓	✓	✓	✓	✓	
5	* Fuel injection	<ul style="list-style-type: none">• Check engine idle speed.	✓	✓	✓	✓	✓	✓	
6	* Exhaust system	<ul style="list-style-type: none">• Check for leakage.• Tighten if necessary.• Replace gasket(s) if necessary.	✓	✓	✓	✓	✓	✓	
7	* Evaporative emission control system	<ul style="list-style-type: none">• Check control system for damage.• Replace if necessary.	Every 12000 mi (19000 km)						

Periodic maintenance and adjustment

EAU63454

General maintenance and lubrication chart

No.	ITEM	ROUTINE × 1000 mi × 1000 km month	INITIAL	ODOMETER READINGS					
			0.6	4	8	12	16	20	
			1	7	13	19	25	31	
			1	6	12	18	24	30	
1	* Diagnostic system check	<ul style="list-style-type: none"> Perform dynamic inspection using Yamaha diagnostic tool. Check the error codes. 	✓	✓	✓	✓	✓	✓	
2	* Air filter element	• Replace.	Every 12000 mi (19000 km)						
3	* Pre air filter element	• Clean.	Every 12000 mi (19000 km)						
4	* Sub air filter element	• Replace.	Every 12000 mi (19000 km)						
5	Air filter check hose	• Clean.	✓	✓	✓	✓	✓	✓	
6	V-belt case air filter element	• Clean.		✓	✓	✓	✓	✓	
7	* Front brake	<ul style="list-style-type: none"> Check operation, fluid level, and for fluid leakage. Replace brake pads if necessary. 	✓	✓	✓	✓	✓	✓	
8	* Rear brake	<ul style="list-style-type: none"> Check operation, fluid level, and for fluid leakage. Replace brake pads if necessary. 	✓	✓	✓	✓	✓	✓	
9	* Brake hoses	<ul style="list-style-type: none"> Check for cracks or damage. Check for correct routing and clamping. 	✓	✓	✓	✓	✓	✓	
		• Replace.	Every 4 years						
10	* Brake fluid	• Change.	Every 2 years						
11	* Wheels	<ul style="list-style-type: none"> Check runout and for damage. Replace if necessary. 		✓	✓	✓	✓	✓	
12	* Tires	<ul style="list-style-type: none"> Check tread depth and for damage. Replace if necessary. Check air pressure. Correct if necessary. 		✓	✓	✓	✓	✓	
13	* Wheel bearings	<ul style="list-style-type: none"> Check bearings for smooth operation. Replace if necessary. 	✓	✓	✓	✓	✓	✓	

Periodic maintenance and adjustment

No.	ITEM	ROUTINE × 1000 mi × 1000 km month	INITIAL	ODOMETER READINGS					
			0.6	4	8	12	16	20	
			1	7	13	19	25	31	
			1	6	12	18	24	30	
14	Steering bearings	<ul style="list-style-type: none"> Check bearing assemblies for looseness. Moderately repack with lithium-soap-based grease. 	✓	✓	✓	✓	✓	✓	
15	Chassis fasteners	<ul style="list-style-type: none"> Check all chassis fitting and fasteners. Correct if necessary. 		✓	✓	✓	✓	✓	
16	Front brake lever pivot shaft	<ul style="list-style-type: none"> Apply silicone grease lightly. 		✓	✓	✓	✓	✓	
17	Rear brake lever pivot shaft	<ul style="list-style-type: none"> Apply silicone grease lightly. 		✓	✓	✓	✓	✓	
18	Centerstand and sidestand pivots	<ul style="list-style-type: none"> Check operation. Apply lithium-soap-based grease lightly. 		✓	✓	✓	✓	✓	
19	Sidestand switch	<ul style="list-style-type: none"> Check operation and replace if necessary. 	✓	✓	✓	✓	✓	✓	
20	Front fork	<ul style="list-style-type: none"> Check operation and for oil leakage. Replace if necessary. 		✓	✓	✓	✓	✓	
21	Shock absorber assemblies	<ul style="list-style-type: none"> Check operation and for oil leakage. Replace if necessary. 		✓	✓	✓	✓	✓	
22	Engine oil	<ul style="list-style-type: none"> Check oil level and vehicle for oil leakage. Change. 	✓	✓	✓	✓	✓	✓	
23	Engine oil filter element	<ul style="list-style-type: none"> Replace. 	✓	Every 12000 mi (19000 km)					
24	Cooling system	<ul style="list-style-type: none"> Check coolant level and vehicle for coolant leakage. Change coolant. 		✓	✓	✓	✓	✓	
25	Final transmission oil	<ul style="list-style-type: none"> Check vehicle for oil leakage. Change. 	✓	✓	✓	✓	✓	✓	
26	V-belt	<ul style="list-style-type: none"> Replace. 		When the V-belt replacement indicator flashes					
27	Front and rear brake switches	<ul style="list-style-type: none"> Check operation. 	✓	✓	✓	✓	✓	✓	
28	Control cables	<ul style="list-style-type: none"> Lubricate. 		✓	✓	✓	✓	✓	

Periodic maintenance and adjustment

No.	ITEM	ROUTINE × 1000 mi × 1000 km month	INITIAL	ODOMETER READINGS				
			0.6	4	8	12	16	20
			1	7	13	19	25	31
			1	6	12	18	24	30
29	Throttle grip	<ul style="list-style-type: none"> Check operation. Check throttle grip free play, and adjust if necessary. Lubricate cable and grip housing. 		✓	✓	✓	✓	✓
30	Lights, signals and switches	<ul style="list-style-type: none"> Check operation. Adjust headlight beam. 	✓	✓	✓	✓	✓	✓

EAUB2340

TIP

- Engine air filter and V-belt air filter
 - The engine air filter uses a disposable oil-coated paper element. This element cannot be cleaned with compressed air, it must be replaced.
 - All filter elements must be serviced more frequently if you often ride in the rain or dusty conditions.
- Hydraulic brake service
 - Regularly check the brake fluid levels and replenish the reservoirs as needed.
 - Replace the internal components of the brake master cylinders and calipers, and change the brake fluid every two years.
 - Replace the brake hoses every four years or sooner if cracked or damaged.

Periodic maintenance and adjustment

Removing and installing the panel

EAU18752


The panel shown needs to be removed to perform some of the maintenance jobs described in this chapter. Refer to this section each time the panel needs to be removed and installed.



1. Panel A


To install the panel

Place the panel in the original position, and then install the screws.



1. Panel A

EAU78530




Panel A

8

To remove the panel

Remove the screws, and then pull the panel outward and slide it forward as shown.



1. Screw

Periodic maintenance and adjustment

EAU19623

Checking the spark plug


The spark plug is an important engine component, which should be checked periodically, preferably by a Yamaha dealer. Since heat and deposits will cause any spark plug to slowly erode, it should be removed and checked in accordance with the periodic maintenance and lubrication chart. In addition, the condition of the spark plug can reveal the condition of the engine.

The porcelain insulator around the center electrode of the spark plug should be a medium-to-light tan (the ideal color when the vehicle is ridden normally). If the spark plug shows a distinctly different color, the engine could be operating improperly. Do not attempt to diagnose such problems yourself. Instead, have a Yamaha dealer check the vehicle.

If the spark plug shows signs of electrode erosion and excessive carbon or other deposits, it should be replaced.

Specified spark plug:
NGK/LMAR8A-9

Before installing a spark plug, the spark plug gap should be measured with a wire thickness gauge and, if necessary, adjusted to specification.



1. Spark plug gap

Spark plug gap:
0.8–0.9 mm (0.031–0.035 in)

Clean the surface of the spark plug gasket and its mating surface, and then wipe off any grime from the spark plug threads.

Tightening torque:
Spark plug:
13 N·m (1.3 kgf·m, 9.6 lb·ft)

TIP


If a torque wrench is not available when installing a spark plug, a good estimate of the correct torque is 1/4–1/2 turn past finger tight. However, the spark plug should be tightened to the specified torque as soon as possible.

Periodic maintenance and adjustment

EAU36112

EAU79020

Canister



1. Canister
2. Canister breather hose

This model is equipped with a canister to prevent the discharging of fuel vapor into the atmosphere. Before operating this vehicle, make sure to check the following:

- Check each hose connection.
- Check each hose and canister for cracks or damage. Replace if damaged.
- Make sure that the canister breather is not blocked, and if necessary, clean it.

Engine oil and oil filter element


The engine oil level should be checked before each ride. In addition, the oil must be changed and the oil filter element replaced at the intervals specified in the periodic maintenance and lubrication chart.

To check the engine oil level

1. Place the vehicle on a level surface and hold it in an upright position. A slight tilt to the side can result in a false reading.
2. Start the engine, warm it up for several minutes, and then turn it off.
3. Wait a few minutes until the oil settles, and then check the oil level through the check window located at the bottom-right side of the crankcase.

TIP

The engine oil should be between the minimum and maximum level marks.




1. Engine oil level check window
2. Maximum level mark
3. Minimum level mark

Periodic maintenance and adjustment


- If the engine oil is below the minimum level mark, add sufficient oil of the recommended type to raise it to the correct level.

To change the engine oil (with or without oil filter element replacement)

- Start the engine, warm it up for several minutes, and then turn it off.
- Place an oil pan under the engine to collect the used oil.
- Remove the engine oil filler cap and its O-ring, and then remove the engine oil drain bolt and its gasket to drain the oil from the crankcase.
- Check the O-ring for damage, and replace it if necessary.



- Engine oil filler cap
- O-ring




- Engine oil drain bolt
- Gasket

TIP

Skip steps 5–7 if the oil filter element is not being replaced.


- Remove the oil filter element cover by removing the bolts.



- Bolt
- Oil filter element cover

- Remove and replace the oil filter element and O-ring.

Periodic maintenance and adjustment



- 1. Oil filter element
- 2. O-ring

- 7. Install the oil filter element cover by installing the bolts, then tightening them to the specified torque.

Tightening torque:

Oil filter element cover bolt:
10 N·m (1.0 kgf·m, 7.4 lb·ft)

TIP

Make sure that the O-ring is properly seated.

- 8. Install the engine oil drain bolt and its new gasket, and then tighten the bolt to the specified torque.

Tightening torque:

Engine oil drain bolt:
20 N·m (2.0 kgf·m, 15 lb·ft)

- 9. Refill with the specified amount of the recommended engine oil.

Recommended engine oil:

See page 10-1

Oil quantity:

Oil change:

1.50 L (1.59 US qt, 1.32 Imp.qt)

With oil filter removal:

1.60 L (1.69 US qt, 1.41 Imp.qt)

TIP

Be sure to wipe off spilled oil on any parts after the engine and exhaust system have cooled down.

NOTICE

Make sure that no foreign material enters the crankcase.


- 10. Install and tighten the oil filler cap and its O-ring.
- 11. Start the engine, and then let it idle for several minutes while checking it for oil leakage. If oil is leaking, immediately turn the engine off and check for the cause.
- 12. Turn the engine off, and then check the oil level and correct it if necessary.

Periodic maintenance and adjustment

Final transmission oil


The final transmission case must be checked for oil leakage before each ride. If any leakage is found, have a Yamaha dealer check and repair the scooter. In addition, the final transmission oil must be changed as follows at the intervals specified in the periodic maintenance and lubrication chart.

1. Start the engine, warm up the final transmission oil by riding the scooter for several minutes, and then stop the engine.
2. Place the scooter on the center-stand.
3. Place an oil pan under the final transmission case to collect the used oil.
4. Remove the final transmission oil filler cap and its O-ring from the final transmission case.



1. Final transmission oil filler cap
2. O-ring

5. Remove the final transmission oil drain bolt and its gasket to drain the oil from the final transmission case.



1. Final transmission oil drain bolt
2. Gasket

6. Install the final transmission oil drain bolt and its new gasket, and then tighten the bolt to the specified torque.

Tightening torque:

Final transmission oil drain bolt:
20 N·m (2.0 kgf·m, 15 lb·ft)

7. Refill with the specified amount of the recommended final transmission oil. **WARNING! Make sure that no foreign material enters the final transmission case. Make sure that no oil gets on the tire or wheel.** [EWA11312]

Recommended final transmission oil:

See page 10-1.

Oil quantity:

0.20 L (0.21 US qt, 0.18 Imp. qt)

8. Install the final transmission oil filler cap and its new O-ring, and then tighten the oil filler cap.
9. Check the final transmission case for oil leakage. If oil is leaking, check for the cause.

Periodic maintenance and adjustment

EAU20071

Coolant

The coolant level should be checked before each ride. In addition, the coolant must be changed at the intervals specified in the periodic maintenance and lubrication chart.

EAU78580

To check the coolant level

1. Place the vehicle on the center-stand.


TIP

- The coolant level must be checked on a cold engine since the level varies with engine temperature.
 - Make sure that the vehicle is positioned straight up when checking the coolant level. A slight tilt to the side can result in a false reading.
2. Check the coolant level through the check window.

8


TIP

The coolant should be between the minimum and maximum level marks.




1. Coolant level check window
2. Maximum level mark
3. Minimum level mark

3. If the coolant is at or below the minimum level mark, remove the left floorboard mat by pulling it up.



1. Floorboard mat

4. Remove the coolant reservoir cover.



1. Coolant reservoir cover


5. Remove the coolant reservoir cap, add coolant to the maximum level mark, and then install the reservoir cap. **WARNING! Remove only the coolant reservoir cap. Never attempt to remove the radiator cap when the engine is hot.**

[EWA15162]

NOTICE: If coolant is not available, use distilled water or soft tap water instead. Do not use hard water or salt water since it is harmful to the engine. If water has been used instead of coolant, replace it with coolant as soon as possible, otherwise the cooling system will not

Periodic maintenance and adjustment

be protected against frost and corrosion. If water has been added to the coolant, have a Yamaha dealer check the anti-freeze content of the coolant as soon as possible, otherwise the effectiveness of the coolant will be reduced. [ECA10473]



1. Coolant reservoir cap

Coolant reservoir capacity (up to the maximum level mark):
0.18 L (0.19 US qt, 0.16 Imp. qt)

6. Install the coolant reservoir cover.
7. Place the left floorboard mat in the original position and push it downward to secure it.

Changing the coolant

The coolant must be changed at the intervals specified in the periodic maintenance and lubrication chart. Have a Yamaha dealer change the coolant.

WARNING! Never attempt to remove the radiator cap when the engine is hot. [EWA10382]


EAU33032

Air filter and V-belt case air filter elements

EAU78574

The air filter element and the sub air filter element should be replaced, and the pre air filter element and the V-belt case air filter element should be cleaned at the intervals specified in the periodic maintenance and lubrication chart. Service the air filter elements more frequently if you are riding in unusually wet or dusty areas. The air filter check hose must be frequently checked and cleaned if necessary.

Cleaning the air filter check hose



1. Air filter check hose

1. Check the hose on the rear side of the air filter case for accumulated dirt or water.
2. If dirt or water is visible, remove the hose from the clamp, clean it, and then install it.


TIP

If dirt or water was found in the check hose, be sure to check the air filter element for excessive dirt or damage and replace it if necessary.

Periodic maintenance and adjustment


Replacing the air filter element and sub air filter element and cleaning the pre air filter element

1. Place the vehicle on the center-stand.
2. Remove the rubber plugs.



1. Rubber plug


3. Remove the air filter case cover by removing the screws.




1. Air filter case cover

2. Screw

4. Pull the air filter element and sub air filter element out.



1. Air filter element



1. Sub air filter element


2. Air filter case cover

5. Insert a new sub air filter element into the air filter case cover.
6. Insert a new air filter element into the air filter case. **NOTICE: Make sure that the air filter element is properly seated in the air filter case. The engine should never be operated without the air filter element installed, otherwise the piston(s) and/or cylinder(s) may become excessively worn.**


[ECA10482]

7. Pull the pre air filter element out, and then blow out the dirt with compressed air as shown.

Periodic maintenance and adjustment




1. Pre air filter element
2. Air filter case cover



8. Check the pre air filter element for damage, and replace it if necessary.
9. Insert the pre air filter element into the air filter case cover.
10. Install the air filter case cover by installing the screws.

TIP

The long screw should be installed as shown.




1. Long screw

11. Install the rubber plugs.

Cleaning the V-belt case air filter element


1. Place the vehicle on the center-stand.
2. Remove the air filter case cover. (See the previous section.)
3. Remove the V-belt case cover screws.



1. Screw


4. Remove the air filter case bolts.

Periodic maintenance and adjustment




1. Bolt

5. Lift up the air filter case slightly, remove the rear wheel sensor lead from the holder, and then remove the V-belt case cover.




1. Rear wheel sensor lead
2. Lead holder

6. Remove the V-belt case air filter cover by removing the bolts.




1. V-belt case air filter cover
2. Bolt

7. Remove the air filter element, and then blow out the dirt with compressed air from the clean side as shown.



1. V-belt case air filter element




1. Clean side

8. Check the V-belt case air filter element for damage and replace it if necessary.
9. Insert the element into the V-belt case.
10. Install the V-belt case air filter cover by installing the bolts.
11. Install the rear wheel sensor lead into the holder at the white tape on the lead as shown.

Periodic maintenance and adjustment

EAU21386



- 1. Rear wheel sensor lead
- 2. White tape
- 3. Lead holder

- 12. Install the air filter case bolts, and then tighten the bolts to the specified torque.


Tightening torque:

Bolt:
10 N·m (1.0 kgf·m, 7.4 lb·ft)

- 13. Install the V-belt case cover by installing the screws.
- 14. Install the air filter case cover by installing the screws.

Checking the throttle grip free play

Measure the throttle grip free play as shown.



- 1. Throttle grip free play

Throttle grip free play:

3.0–5.0 mm (0.12–0.20 in)

Periodically check the throttle grip free play and, if necessary, have a Yamaha dealer adjust it.

Periodic maintenance and adjustment

EAUJ21403

EAU54220

Valve clearance

The valves are an important engine component, and since valve clearance changes with use, they must be checked and adjusted at the intervals specified in the periodic maintenance chart. Unadjusted valves can result in improper air-fuel mixture, engine noise, and eventually engine damage. To prevent this from occurring, have your Yamaha dealer check and adjust the valve clearance at regular intervals.

TIP

This service must be performed when the engine is cold.

Tires

Tires are the only contact between the vehicle and the road. Safety in all conditions of riding depends on a relatively small area of road contact. Therefore, it is essential to maintain the tires in good condition at all times and replace them at the appropriate time with the specified tires.

Tire air pressure

The tire air pressure should be checked and, if necessary, adjusted before each ride.

EWA10504



WARNING

Operation of this vehicle with improper tire pressure may cause severe injury or death from loss of control.

- The tire air pressure must be checked and adjusted on cold tires (i.e., when the temperature of the tires equals the ambient temperature).
- The tire air pressure must be adjusted in accordance with the riding speed and with the total weight of rider, passenger, cargo, and accessories approved for this model.

Periodic maintenance and adjustment

Tire air pressure (measured on cold tires):

Up to 90 kg (198 lb) load:

Front:

200 kPa (2.00 kgf/cm², 29 psi)

Rear:

225 kPa (2.25 kgf/cm², 33 psi)

90 kg (198 lb) to maximum load:

Front:

200 kPa (2.00 kgf/cm², 29 psi)

Rear:

225 kPa (2.25 kgf/cm², 33 psi)

Maximum load*:

161 kg (355 lb)

* Total weight of rider, passenger, cargo and accessories

Minimum tire tread depth (front and rear):

1.0 mm (0.04 in)

EWA10523

WARNING


- It is dangerous to ride with a worn-out tire. When a tire tread begins to show crosswise lines, have a Yamaha dealer replace the tire immediately. Brakes, tires and related wheel parts replacement should also be left to a Yamaha dealer.
- Ride at moderate speeds after changing a tire since the tire surface must first be "broken in" for it to develop its optimal characteristics.

EWA10512

WARNING

Never overload your vehicle. Operation of an overloaded vehicle could cause an accident.

Tire inspection



1. Tire sidewall
2. Tire wear indicator
3. Tire tread depth

The tires must be checked before each ride. If a tire tread shows crosswise lines (minimum tread depth), if the tire has a nail or glass fragments in it, or if the sidewall is cracked, contact a Yamaha dealer immediately and have the tire replaced.

Tire information

This model is equipped with tubeless tires and tire air valves.

Tires age, even if they have not been used or have only been used occasionally. Cracking of the tread and sidewall rubber, sometimes accompanied by carcass deformation, is an evidence of ageing. Old and aged tires shall be checked by tire specialists to ascertain their suitability for further use.

EWA10482

WARNING

The front and rear tires should be of the same make and design, otherwise the handling characteristics of the vehicle may be different, which could lead to an accident.

After extensive tests, only the tires listed below have been approved for this model by Yamaha.

Periodic maintenance and adjustment

EAU21663

Front tire:

Size:

120/70-15 M/C 56P

Manufacturer/model:

DUNLOP/SCOOTSMART

Rear tire:

Size:

140/70-14 M/C 62P

Manufacturer/model:

DUNLOP/SCOOTSMART

Cast wheels

To maximize the performance, durability, and safe operation of your vehicle, note the following points regarding the specified wheels.

- The wheel rims should be checked for cracks, bends, warp-age or other damage before each ride. If any damage is found, have a Yamaha dealer replace the wheel. Do not attempt even the smallest repair to the wheel. A de-formed or cracked wheel must be replaced.
- The wheel should be balanced whenever either the tire or wheel has been changed or replaced. An unbalanced wheel can result in poor performance, adverse han-dling characteristics, and a short-ened tire life.


Periodic maintenance and adjustment

Checking the front and rear brake lever free play

EAU50951


braking performance, which may result in loss of control and an accident.

Front



1. No brake lever free play

Rear



1. No brake lever free play

There should be no free play at the brake lever ends. If there is free play, have a Yamaha dealer inspect the brake system.

EWA14212

WARNING


A soft or spongy feeling in the brake lever can indicate the presence of air in the hydraulic system. If there is air in the hydraulic system, have a Yamaha dealer bleed the system before operating the vehicle. Air in the hydraulic system will diminish the

Periodic maintenance and adjustment

EAU22312


Checking the front and rear brake pads

Front brake



1. Brake pad wear indicator

Rear brake



1. Brake pad wear indicator

The front and rear brake pads must be checked for wear at the intervals specified in the periodic maintenance and lubrication chart. Each brake pad is provided with a wear indicator, which allows you to check the brake pad wear without having to disassemble the brake. To check the brake pad wear, check the position of the wear indicator while applying the brake. If a brake pad has worn to the point that the wear indicator almost touches the brake disc, have a Yamaha dealer replace the brake pads as a set.

EAU22583

Checking the brake fluid level

Before riding, check that the brake fluid is above the minimum level mark. Check the brake fluid level with the reservoir in an upright position. Replenish the brake fluid if necessary.


Specified brake fluid:
DOT 4

ECA17641

NOTICE


Brake fluid may damage painted surfaces or plastic parts. Always clean up spilled fluid immediately.

Front brake



1. Minimum level mark

Rear brake



1. Minimum level mark

As the brake pads wear, it is normal for the brake fluid level to gradually go down.

Periodic maintenance and adjustment

EAU22734

- A low brake fluid level may indicate worn brake pads or brake system leakage; therefore, be sure to check the brake pads for wear and the brake system for leakage.
- If the brake fluid level goes down suddenly, have a Yamaha dealer check the cause before further riding.

EWA15991

WARNING

Improper maintenance can result in loss of braking ability. Observe these precautions:

- Insufficient brake fluid may allow air to enter the brake system, reducing braking performance.
- Clean the filler cap before removing. Use only DOT 4 brake fluid from a sealed container.
- Use only the specified brake fluid; otherwise, the rubber seals may deteriorate, causing leakage.
- Refill with the same type of brake fluid. Adding a brake fluid other than DOT 4 may result in a harmful chemical reaction.
- Be careful that water does not enter the brake fluid reservoir when refilling. Water will significantly lower the boiling point of the fluid and may result in vapor lock.

Changing the brake fluid

Have a Yamaha dealer change the brake fluid every 2 years. In addition, have the seals of the master cylinders and brake calipers, as well as the brake hoses replaced at the intervals listed below or sooner if they are damaged or leaking.

- Brake seals: every 2 years
- Brake hoses: every 4 years

Periodic maintenance and adjustment

EAUJ0311

EAUJ23098

Checking the V-belt

The V-belt must be checked and replaced by a Yamaha dealer at the intervals specified in the periodic maintenance and lubrication chart.

Checking and lubricating the cables

The operation of all control cables and the condition of the cables should be checked before each ride, and the cables and cable ends should be lubricated if necessary. If a cable is damaged or does not move smoothly, have a Yamaha dealer check or replace it. **WARNING! Damage to the outer housing of cables may result in internal rusting and cause interference with cable movement. Replace damaged cables as soon as possible to prevent unsafe conditions.** [EWA10712]

Recommended lubricant:

Yamaha cable lubricant or other suitable cable lubricant

Periodic maintenance and adjustment

EAU49921


Checking and lubricating the throttle grip and cable

The operation of the throttle grip should be checked before each ride. In addition, the cable should be lubricated by a Yamaha dealer at the intervals specified in the periodic maintenance chart.


EAU23173

Lubricating the front and rear brake levers

Front brake lever



Rear brake lever




The pivoting points of the front and rear brake levers must be lubricated at the intervals specified in the periodic maintenance and lubrication chart.

Recommended lubricant:
Silicone grease

Periodic maintenance and adjustment

EAU23215

Checking and lubricating the centerstand and sidestand



The operation of the centerstand and sidestand should be checked before each ride, and the pivots and metal-to-metal contact surfaces should be lubricated if necessary.

EWA10742

WARNING

If the centerstand or sidestand does not move up and down smoothly, have a Yamaha dealer check or repair it. Otherwise, the centerstand or sidestand could contact the ground and distract the operator, resulting in a possible loss of control.

Recommended lubricant:
Lithium-soap-based grease

Checking the front fork

EAU23273


The condition and operation of the front fork must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.

To check the condition

Check the inner tubes for scratches, damage and excessive oil leakage.

To check the operation

1. Place the vehicle on a level surface and hold it in an upright position. **WARNING! To avoid injury, securely support the vehicle so there is no danger of it falling over.** [EWA10752]
2. While applying the front brake, push down hard on the handlebars several times to check if the front fork compresses and rebounds smoothly.



ECA10591

NOTICE

If any damage is found or the front fork does not operate smoothly, have a Yamaha dealer check or repair it.


Periodic maintenance and adjustment

EAU45512

Checking the steering


Worn or loose steering bearings may cause danger. Therefore, the operation of the steering must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.

1. Place the vehicle on the center-stand. **WARNING! To avoid injury, securely support the vehicle so there is no danger of it falling over.** [EWA10752]
2. Hold the lower ends of the front fork legs and try to move them forward and backward. If any free play can be felt, have a Yamaha dealer check or repair the steering.



EAU23292

Checking the wheel bearings




The front and rear wheel bearings must be checked at the intervals specified in the periodic maintenance and lubrication chart. If there is play in the wheel hub or if the wheel does not turn smoothly, have a Yamaha dealer check the wheel bearings.

Periodic maintenance and adjustment

EAU60691

Battery



1. Negative battery lead (black)
2. Positive battery lead (red)
3. Battery

The battery is located behind panel A. (See page 8-7.)

This model is equipped with a VRLA (Valve Regulated Lead Acid) battery. There is no need to check the electrolyte or to add distilled water. However, the battery lead connections need to be checked and, if necessary, tightened.

ECA16522

NOTICE

To charge a VRLA (Valve Regulated Lead Acid) battery, a special (constant-voltage) battery charger is required. Using a conventional battery charger will damage the battery.

To store the battery

1. If the vehicle will not be used for more than one month, remove the battery, fully charge it, and then place it in a cool, dry place.
NOTICE: When removing the battery, be sure to turn the main switch off, then disconnect the negative lead before disconnecting the positive lead. (ECA16304)
2. If the battery will be stored for more than two months, check it at least once a month and fully charge it if necessary.

8 **WARNING**

- **Electrolyte is poisonous and dangerous since it contains sulfuric acid, which causes severe burns. Avoid any contact with skin, eyes or clothing and always shield your eyes when working near batteries. In case of contact, administer the following FIRST AID.**
 - **EXTERNAL:** Flush with plenty of water.
 - **INTERNAL:** Drink large quantities of water or milk and immediately call a physician.
 - **EYES:** Flush with water for 15 minutes and seek prompt medical attention.

Periodic maintenance and adjustment

EAU78242

3. Fully charge the battery before installation. **NOTICE:** When installing the battery, be sure to turn the main switch off, then connect the positive lead before connecting the negative lead.

[ECA16842]

4. After installation, make sure that the battery leads are properly connected to the battery terminals.

ECA16531

NOTICE


Always keep the battery charged. Storing a discharged battery can cause permanent battery damage.

Replacing the fuses

The main fuse and the fuse boxes, which contain the fuses for the individual circuits, are located under panel A. (See page 8-7.)


TIP

To access the main fuse, remove the starter relay cover as shown.



1. Fuse box
2. Main fuse
3. Spare main fuse
4. Starter relay cover

Periodic maintenance and adjustment



1. Signaling system fuse
2. ABS control unit fuse
3. Main fuse 2
4. Radiator fan motor fuse
5. Backup fuse
6. Spare fuse
7. ABS motor fuse
8. ABS solenoid fuse
9. Turn signal light and hazard fuse
10. Terminal fuse 1
11. Answer back fuse

If a fuse is blown, replace it as follows.

1. Turn the main switch off and turn off the electrical circuit in question.
2. Remove the blown fuse, and then install a new fuse of the specified amperage. **WARNING! Do not use a fuse of a higher amperage rating than recommended to avoid causing extensive damage to the electrical system and possibly a fire.** [EWA15132]

Specified fuses:

- Main fuse:
30.0 A
- Main fuse 2:
7.5 A
- Terminal fuse 1:
2.0 A
- Signaling system fuse:
10.0 A
- Radiator fan motor fuse:
7.5 A
- Backup fuse:
15.0 A
- Turn signal light and hazard fuse:
7.5 A
- ABS control unit fuse:
7.5 A
- ABS motor fuse:
30.0 A
- ABS solenoid fuse:
15.0 A
- Answer back fuse:
2.0 A

3. Turn the main switch on and turn on the electrical circuit in question to check if the device operates.
4. If the fuse immediately blows again, have a Yamaha dealer check the electrical system.

Periodic maintenance and adjustment

EAU64070

EAU54502

Headlights

This model is equipped with LED-type headlights.

If a headlight does not come on, have a Yamaha dealer check its electrical circuit.

EGA16581

NOTICE

Do not affix any type of tinted film or stickers to the headlight lens.

Auxiliary lights

This model is equipped with LED-type auxiliary lights.

If an auxiliary light does not come on, have a Yamaha dealer check it.

Periodic maintenance and adjustment

EAUJ70540

EAUJ43006


Brake/tail light

This model is equipped with an LED-type brake/tail light.

If the brake/tail light does not come on, have a Yamaha dealer check it.


Replacing a turn signal light bulb

1. Remove the turn signal light unit by removing the screw.



1. Turn signal light lens
2. Screw


2. Remove the turn signal light bulb socket (together with the bulb) by turning it counterclockwise.



1. Turn signal light bulb socket
3. Remove the burnt-out bulb by pulling it out.

Periodic maintenance and adjustment

EAU78560




1. Turn signal light bulb

4. Insert a new bulb into the socket.
5. Install the socket (together with the bulb) by turning it clockwise.
6. Install the turn signal light unit by installing the screw. **NOTICE: Do not overtighten the screw, otherwise the lens may break.**

[ECA11192]


Replacing the license plate light bulb

1. Remove the license plate light unit by removing the bolts and plate, and then remove the license plate light bulb socket (together with the bulb) by pulling it out.



1. License plate light unit
2. Bolt
3. License plate light bulb socket
4. Plate

2. Remove the burnt-out bulb by pulling it out.



1. License plate light bulb

3. Insert a new bulb into the socket.
4. Install the socket (together with the bulb) by pushing it in, and then install the license plate light unit by installing the plate and bolts.

Periodic maintenance and adjustment

EAU60701

Troubleshooting

Although Yamaha vehicles receive a thorough inspection before shipment from the factory, trouble may occur during operation. Any problem in the fuel, compression, or ignition systems, for example, can cause poor starting and loss of power.

The following troubleshooting charts represent quick and easy procedures for checking these vital systems yourself. However, should your vehicle require any repair, take it to a Yamaha dealer, whose skilled technicians have the necessary tools, experience, and know-how to service the vehicle properly.

Use only genuine Yamaha replacement parts. Imitation parts may look like Yamaha parts, but they are often inferior, have a shorter service life and can lead to expensive repair bills.

EWA15142



WARNING

When checking the fuel system, do not smoke, and make sure there are no open flames or sparks in the area, including pilot lights from water heaters or furnaces. Gasoline or gasoline vapors can ignite or explode, causing severe injury or property damage.

EAU76551

Smart key system troubleshooting

Please check the following items when the smart key system does not work.

- Is the smart key turned on? (See page 4-6.)
- Is the smart key battery discharged? (See page 4-7.)

- Is the smart key battery installed correctly? (See page 4-7.)
- Is the smart key being used in a location with strong radio waves or other electromagnetic noise? (See page 4-1.)
- Are you using the smart key that is registered to the vehicle?
- Is the vehicle battery discharged? When the vehicle battery is discharged, the smart key system will not operate. Please have the vehicle battery charged or replaced. (See page 8-29.)

If the smart key system does not work after checking the above items, have a Yamaha dealer check the smart key system.


TIP

See Emergency mode on page 8-38 for information on starting the engine without the smart key.


Troubleshooting charts

Starting problems or poor engine performance


1. Fuel



2. Battery



3. Ignition



4. Compression



Periodic maintenance and adjustment


Engine overheating

EWAT1041



WARNING

- Do not remove the radiator cap when the engine and radiator are hot. Scalding hot fluid and steam may be blown out under pressure, which could cause serious injury. Be sure to wait until the engine has cooled.
- Place a thick rag, like a towel, over the radiator cap, and then slowly rotate the cap counterclockwise to the detent to allow any residual pressure to escape. When the hissing sound has stopped, press down on the cap while turning it counterclockwise, and then remove the cap.



8

TIP

If coolant is not available, tap water can be temporarily used instead, provided that it is changed to the recommended coolant as soon as possible.

Periodic maintenance and adjustment


EAU76561

Emergency mode


When the smart key is lost or damaged, or its battery has discharged, the vehicle can still be turned on and the engine started. You will need the smart key system identification number.

To operate the vehicle in emergency mode

1. Stop the vehicle in a safe place and turn the main switch to "OFF".
2. Push the main switch knob for 5 seconds until the smart key system indicator light flashes once, then release it. Repeat two more times. The smart key system indicator light will come on for three seconds to indicate the transition to emergency mode.



1. Smart key system indicator light "key symbol"
3. After the smart key system indicator light goes off, input the identification number as follows.



1. Identification number card
2. Smart key (inside)
3. Identification number
4. Inputting the identification number is done by counting the number of flashes of the smart key system indicator light. For example, if the identification number is 123456: Push and hold the knob.

The smart key system indicator light will start to flash.



Release the knob after the smart key system indicator light flashes once.

The first digit of the identification number has been set as "1".

Push and hold the knob again.



Periodic maintenance and adjustment

Release the knob after the smart key system indicator light flashes twice.



The second digit has been set as "2".



Repeat the above procedure until all digits of the identification number have been set. The smart key system indicator light will flash for 10 seconds if the correct identification number was entered.

TIP

When one of the following situations applies, emergency mode will be terminated and the smart key system indicator light will flash quickly for 3 seconds. In this case, start over again from step 2.

- When there are no knob operations for 10 seconds during the identification number input process.
- When the smart key system indicator light is allowed to flash nine or more times.
- The identification number is not entered correctly.

5. While the smart key system indicator light is on, push the knob once more to complete emergency mode access. The smart key indicator light will go off and then come back on for approximately 4 seconds.

6. While the smart key system indicator light is on, turn the main switch to "ON". The vehicle can now be operated normally.

Matte color caution

ECA15193

NOTICE

Some models are equipped with matte colored finished parts. Be sure to consult a Yamaha dealer for advice on what products to use before cleaning the vehicle. Using a brush, harsh chemical products or cleaning compounds when cleaning these parts will scratch or damage their surface. Wax also should not be applied to any matte colored finished parts.

Care

While the open design of a scooter reveals the attractiveness of the technology, it also makes it more vulnerable. Rust and corrosion can develop even if high-quality components are used. A rusty exhaust pipe may go unnoticed on a car, however, it detracts from the overall appearance of a scooter. Frequent and proper care does not only comply with the terms of the warranty, but it will also keep your scooter looking good, extend its life and optimize its performance.

Before cleaning

1. Cover the muffler outlet with a plastic bag after the engine has cooled down.
2. Make sure that all caps and covers as well as all electrical couplers and connectors, including the spark plug cap, are tightly installed.
3. Remove extremely stubborn dirt, like oil burnt onto the crankcase, with a degreasing agent and a brush, but never apply such products onto seals, gaskets and wheel axles. Always rinse the dirt and degreaser off with water.

Cleaning

ECA10784

NOTICE

- Avoid using strong acidic wheel cleaners, especially on spoked wheels. If such products are used on hard-to-remove dirt, do not leave the cleaner on the affected area any longer than in-

Scooter care and storage

structed. Also, thoroughly rinse the area off with water, immediately dry it, and then apply a corrosion protection spray.

- Improper cleaning can damage plastic parts (such as cowlings, panels, windshields, headlight lenses, meter lenses, etc.) and the mufflers. Use only a soft, clean cloth or sponge with water to clean plastic. However, if the plastic parts cannot be thoroughly cleaned with water, diluted mild detergent with water may be used. Be sure to rinse off any detergent residue using plenty of water, as it is harmful to plastic parts.
- Do not use any harsh chemical products on plastic parts. Be sure to avoid using cloths or sponges which have been in contact with strong or abrasive cleaning products, solvent or thinner, fuel (gasoline), rust removers or inhibitors, brake fluid, antifreeze or electrolyte.
- Do not use high-pressure washers or steam-jet cleaners since they cause water seepage and deterioration in the following areas: seals (of wheel and swing-arm bearings, fork and brakes), electric components (couplers, connectors, instruments, switches and lights), breather hoses and vents.
- For scooters equipped with a windshield: Do not use strong cleaners or hard sponges as they will cause dulling or scratching. Some cleaning

compounds for plastic may leave scratches on the windshield. Test the product on a small hidden part of the windshield to make sure that it does not leave any marks. If the windshield is scratched, use a quality plastic polishing compound after washing.

After normal use

Remove dirt with warm water, a mild detergent, and a soft, clean sponge, and then rinse thoroughly with clean water. Use a toothbrush or bottlebrush for hard-to-reach areas. Stubborn dirt and insects will come off more easily if the area is covered with a wet cloth for a few minutes before cleaning.

After riding in the rain, near the sea, or on salt-sprayed roads

Since sea salt or salt sprayed on roads during winter are extremely corrosive in combination with water, carry out the following steps after each ride in the rain, near the sea, or on salt-sprayed roads.

TIP

Salt sprayed on roads in the winter may remain well into spring.

1. Clean the scooter with cold water and a mild detergent after the engine has cooled down. **NOTICE:** Do not use warm water since it increases the corrosive action of the salt. [ECA10792]
2. Apply a corrosion protection spray on all metal, including chrome- and nickel-plated, surfaces to prevent corrosion.

Scooter care and storage

Cleaning the windshield

Avoid using any alkaline or strong acid cleaner, gasoline, brake fluid, or any other solvent. Clean the windshield with a cloth or sponge dampened with a neutral detergent, and after cleaning, thoroughly wash it off with water. For additional cleaning, use Yamaha Windshield Cleaner or other quality cleaner. Some cleaning compounds for plastics may leave scratches on surfaces of the windshield. Before using them, make a test by polishing an area which does not affect your visibility.

After cleaning

1. Dry the scooter with a chamois or an absorbing cloth.
2. Use a chrome polish to shine chrome, aluminum and stainless-steel parts, including the exhaust system. (Even the thermally induced discoloring of stainless-steel exhaust systems can be removed through polishing.)
3. To prevent corrosion, it is recommended to apply a corrosion protection spray on all metal, including chrome- and nickel-plated, surfaces.
4. Use spray oil as a universal cleaner to remove any remaining dirt.
5. Touch up minor paint damage caused by stones, etc.
6. Wax all painted surfaces.
7. Let the scooter dry completely before storing or covering it.

EWAT0943



WARNING

Contaminants on the brakes or tires can cause loss of control.

- **Make sure that there is no oil or wax on the brakes or tires. If necessary, clean the brake discs and brake linings with a regular brake disc cleaner or acetone, and wash the tires with warm water and a mild detergent.**
- **Before operating the scooter test its braking performance and cornering behavior.**

ECAU0022

NOTICE

- **Apply spray oil and wax sparingly and make sure to wipe off any excess.**
- **Never apply oil or wax to any rubber parts, plastic parts or headlight, taillight and meter lenses, but treat them with a suitable care product.**
- **Avoid using abrasive polishing compounds as they will wear away the paint.**

TIP

- Consult a Yamaha dealer for advice on what products to use.
- Washing, rainy weather or humid climates can cause the headlight lens to fog. Turning the headlight on for a short period of time will help remove the moisture from the lens.

Scooter care and storage

EAU36564

Storage

Short-term

Always store your scooter in a cool, dry place and, if necessary, protect it against dust with a porous cover. Be sure the engine and the exhaust system are cool before covering the scooter.

EGA10821

NOTICE

- Storing the scooter in a poorly ventilated room or covering it with a tarp, while it is still wet, will allow water and humidity to seep in and cause rust.
- To prevent corrosion, avoid damp cellars, stables (because of the presence of ammonia) and areas where strong chemicals are stored.

Long-term

Before storing your scooter for several months:

1. Follow all the instructions in the "Care" section of this chapter.
2. Fill up the fuel tank and add fuel stabilizer (if available) to prevent the fuel tank from rusting and the fuel from deteriorating.
3. Perform the following steps to protect the cylinder, piston rings, etc. from corrosion.
 - a. Remove the spark plug cap and spark plug.
 - b. Pour a teaspoonful of engine oil into the spark plug bore.
 - c. Install the spark plug cap onto the spark plug, and then place the spark plug on the cylinder

head so that the electrodes are grounded. (This will limit sparking during the next step.)

- d. Turn the engine over several times with the starter. (This will coat the cylinder wall with oil.)
- e. Remove the spark plug cap from the spark plug, and then install the spark plug and the spark plug cap. **WARNING! To prevent damage or injury from sparking, make sure to ground the spark plug electrodes while turning the engine over.** [EWA10952]

4. Lubricate all control cables and the pivoting points of all levers and pedals as well as of the side-stand/centerstand.
5. Check and, if necessary, correct the tire air pressure, and then lift the scooter so that both of its wheels are off the ground. Alternatively, turn the wheels a little every month in order to prevent the tires from becoming degraded in one spot.
6. Cover the muffler outlet with a plastic bag to prevent moisture from entering it.
7. Remove the battery and fully charge it. Store it in a cool, dry place and charge it once a month. Do not store the battery in an excessively cold or warm place [less than 0 °C (30 °F) or more than 30 °C (90 °F)]. For more information on storing the battery, see page 8-29.

Scooter care and storage

TIP

Make any necessary repairs before storing the scooter.

Specifications

Dimensions:

- Overall length:
2185 mm (86.0 in)
Overall width:
775 mm (30.5 in)
Overall height:
1415/1465 mm (55.7/57.7 in)
Seat height:
795 mm (31.3 in)
Wheelbase:
1540 mm (60.6 in)
Ground clearance:
135 mm (5.31 in)
Minimum turning radius:
2.6 m (8.53 ft)

Weight:


- Curb weight:
180 kg (397 lb)

Engine:

- Combustion cycle:
4-stroke
Cooling system:
Liquid cooled
Valve train:
SOHC
Number of cylinders:
Single cylinder
Displacement:
292 cm³
Bore × stroke:
70.0 × 75.9 mm (2.76 × 2.99 in)
Compression ratio:
10.9 : 1
Starting system:
Electric starter
Lubrication system:
Wet sump

Engine oil:

- Recommended brand:
YAMALUBE
SAE viscosity grades:
10W-40, 10W-50, 15W-40, 20W-40 or
20W-50



- Recommended engine oil grade:
API service SG type or higher, JASO
standard MA or MB

Engine oil quantity:

- Oil change:
1.50 L (1.59 US qt, 1.32 Imp.qt)
With oil filter removal:
1.60 L (1.69 US qt, 1.41 Imp.qt)

Final transmission oil:

- Type:
Motor oil SAE 10W-30 type SE or higher or
Gear oil SAE 85W GL-3
Quantity:
0.20 L (0.21 US qt, 0.18 Imp.qt)

Coolant quantity:

- Coolant reservoir (up to the maximum level
mark):
0.18 L (0.19 US qt, 0.16 Imp.qt)
Radiator (including all routes):
1.10 L (1.16 US qt, 0.97 Imp.qt)

Air filter:

- Air filter element:
Oil-coated paper element

Fuel:

- Recommended fuel:
Regular unleaded gasoline (Gasohol [E10]
acceptable)
Fuel tank capacity:
13 L (3.4 US gal, 2.9 Imp.gal)
Fuel reserve amount:
2.4 L (0.63 US gal, 0.53 Imp.gal)

Fuel injection:

- Throttle body:
ID mark:
B741 00

Spark plug(s):

- Manufacturer/model:
NGK/LMAR8A-9

Spark plug gap:
0.8–0.9 mm (0.031–0.035 in)

Clutch:

Clutch type:
Dry, centrifugal, shoe

Drivetrain:

Primary reduction ratio:
1.000
Final drive:
Gear
Secondary reduction ratio:
7.590 (48/18 x 37/13)
Transmission type:
V-belt automatic

Chassis:

Frame type:
Underbone
Caster angle:
26.5 °
Trail:
95 mm (3.7 in)

Front tire:

Type:
Tubeless
Size:
120/70-15 M/C 58P
Manufacturer/model:
DUNLOP/SCOOTSMART

Rear tire:

Type:
Tubeless
Size:
140/70-14 M/C 62P
Manufacturer/model:
DUNLOP/SCOOTSMART

Loading:

Maximum load:
161 kg (355 lb)
(Total weight of rider, passenger, cargo
and accessories)

Tire air pressure (measured on cold tires):

Up to 90 kg (198 lb) load:
Front:
200 kPa (2.00 kgf/cm², 29 psi)
Rear:
225 kPa (2.25 kgf/cm², 33 psi)
90 kg (198 lb) load - maximum load:
Front:
200 kPa (2.00 kgf/cm², 29 psi)

Rear:
225 kPa (2.25 kgf/cm², 33 psi)

Front wheel:

Wheel type:
Cast wheel
Rim size:
J15M/C x MT3.5

Rear wheel:

Wheel type:
Cast wheel
Rim size:
J14M/C x MT4.0

Front brake:

Type:
Hydraulic single disc brake
Specified brake fluid:
DOT 4

Rear brake:

Type:
Hydraulic single disc brake
Specified brake fluid:
DOT 4

Front suspension:

Type:
Telescopic fork
Spring:
Coil spring
Shock absorber:
Hydraulic damper
Wheel travel:
110 mm (4.3 in)

Rear suspension:

Type:
Unit swing
Spring:
Coil spring
Shock absorber:
Hydraulic damper
Wheel travel:
79 mm (3.1 in)

Electrical system:

System voltage:
12 V
Ignition system:
TCI
Charging system:
AC magneto

Battery:

Model:
GTZ8V

Specifications

Voltage, capacity:
12 V, 7.0 Ah (10 HR)

Backup fuse:
15.0 A

Bulb wattage:

Headlight:

LED

Brake/tail light:

LED

Front turn signal/position light:

21.0 W/5.0 W

Rear turn signal light:

21.0 W

Auxiliary light:

LED

License plate light:

5.0 W

Meter lighting:

LED

High beam indicator light:

LED

Turn signal indicator light:

LED

Engine trouble warning light:

LED

ABS warning light:

LED

Smart key system indicator light:

LED

Traction control system indicator/warning light:

LED

Fuse(s):

Main fuse:

30.0 A

Main fuse 2:

7.5 A

Terminal fuse 1:

2.0 A

Signaling system fuse:

10.0 A

Radiator fan motor fuse:

7.5 A

Turn signal light and hazard fuse:

7.5 A

ABS control unit fuse:

7.5 A

ABS motor fuse:

30.0 A

ABS solenoid fuse:

15.0 A

Answer back fuse:

2.0 A

EAU53562

Identification numbers

Record the vehicle identification number, engine serial number, and the model label information in the spaces provided below. These identification numbers are needed when registering the vehicle with the authorities in your area and when ordering spare parts from a Yamaha dealer.


VEHICLE IDENTIFICATION NUMBER:

ENGINE SERIAL NUMBER:

MODEL LABEL INFORMATION:

Vehicle identification number

EAU26411



1. Vehicle identification number


The vehicle identification number is stamped into the frame.

TIP

The vehicle identification number is used to identify your vehicle and may be used to register it with the licensing authority in your area.

EAU26442

Engine serial number




1. Engine serial number

The engine serial number is stamped into the crankcase.

EAU26501


Model label



1. Model label

The model label is affixed to the inside of the rear storage compartment. (See page 5-20.) Record the information on this label in the space provided. This information will be needed when ordering spare parts from a Yamaha dealer.

Diagnostic connector



1. Diagnostic connector

The diagnostic connector is located as shown.

Vehicle data recording

This model's ECU stores certain vehicle data to assist in the diagnosis of malfunctions and for research and development purposes. This data will be uploaded only when a special Yamaha diagnostic tool is attached to the vehicle, such as when maintenance checks or service procedures are performed. Although the sensors and recorded data will vary by model, the main data points are:

- Vehicle status and engine performance data
- Fuel-injection and emission-related data

Yamaha will not disclose this data to a third party except:

- With the consent of the vehicle owner
- Where obligated by law
- For use by Yamaha in litigation
- For general Yamaha-conducted research purposes when the data is not related to an individual vehicle nor owner

Reporting safety defects

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Yamaha Motor Corporation, U.S.A. If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Yamaha Motor Corporation, U.S.A.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to <http://www.safercar.gov>; or write to: Administrator, NHTSA, 1200 New Jersey Avenue, SE, West Building, Washington, DC 20590. You can also obtain other information about motor vehicle safety from <http://www.safercar.gov>.

Scooter noise regulation

TAMPERING WITH NOISE CONTROL SYSTEM PROHIBITED:

Federal law prohibits the following acts or the causing thereof: (1) The removal or rendering inoperative by any person other than for purposes of maintenance, repair, or replacement of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use or (2) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

"AMONG THOSE ACTS PRESUMED TO CONSTITUTE TAMPERING ARE THE ACTS LISTED BELOW."

These acts include tampering with the following systems; i.e., modification, removal, etc.

Exhaust system

- Muffler
- Exhaust pipe
- Silencer

Intake system

- Air cleaner case
- Air cleaner element
- Intake duct

Maintenance record

Copies of work orders and/or receipts for parts purchased and installed on your vehicle will be required to document that maintenance has been completed in accordance with the emissions warranty. The chart below is printed only as a reminder that maintenance work is required. It is not acceptable proof of maintenance work.

Maintenance interval	Date of service	Mileage	Servicing dealer name and address	Remarks
600 mi (1000 km) or 1 month				
4000 mi (7000 km) or 6 months				
8000 mi (13000 km) or 12 months				
12000 mi (19000 km) or 18 months				
16000 mi (25000 km) or 24 months				
20000 mi (31000 km) or 30 months				
24000 mi (37000 km) or 36 months				
28000 mi (43000 km) or 42 months				
32000 mi (49000 km) or 48 months				
36000 mi (55000 km) or 54 months				
40000 mi (61000 km) or 60 months				

Consumer information

EAU53494

YAMAHA MOTOR CORPORATION, U.S.A. 2015 AND LATER MODEL STREET & DUAL-PURPOSE MOTORCYCLE LIMITED WARRANTY

Yamaha Motor Corporation, U.S.A. hereby warrants that each new Yamaha motorcycle purchased from an authorized Yamaha motorcycle dealer in the continental United States will be free from defects in material and workmanship for the period of time stated herein, subject to certain stated limitations.

THE PERIOD OF WARRANTY for Yamaha motorcycles originally equipped with headlight, stoplight, and turn signals shall be one (1) year from the date of purchase, with no mileage limitation, except for the battery, which is warranted for thirty (30) days from the date of purchase.

MODELS EXCLUDED FROM WARRANTY include those used for non-Yamaha-authorized renting, leasing, or other commercial purposes.

DURING THE PERIOD OF WARRANTY any authorized Yamaha motorcycle dealer will, free of charge, repair or replace, at Yamaha's option, any part adjudged defective by Yamaha due to faulty workmanship or material from the factory. Parts used in warranty repairs will be warranted for the balance of the product's warranty period. All parts replaced under warranty become the property of Yamaha Motor Corporation, U.S.A.

GENERAL EXCLUSIONS from this warranty shall include any failures caused by:

- Competition or racing use.
- Installation of parts or accessories that are not qualitatively equivalent to genuine Yamaha parts.
- Abnormal strain, neglect, or abuse.
- Lack of proper maintenance and off-season storage as described in the Owner's Manual.
- Accident or collision damage.
- Modification to original parts.
- Damage due to improper transportation

SPECIFIC EXCLUSIONS from this warranty shall include parts replaced due to normal wear or routine maintenance.

THE CUSTOMER'S RESPONSIBILITY under this warranty shall be to:

- Operate and maintain the motorcycle as specified in the appropriate Owner's Manual, and
- Give notice to an authorized Yamaha motorcycle dealer of any and all apparent defects within ten (10) days after discovery, and make the machine available at that time for inspection and repairs at such dealer's place of business.

WARRANTY TRANSFER: To transfer the warranty from the original purchaser to any subsequent purchaser, it is imperative that the machine be inspected and registered for warranty by an authorized Yamaha motorcycle dealer. In order for this warranty to remain in effect, this inspection and registration must take place within ten (10) days after transfer. A reasonable dealer-imposed fee may be charged for the inspection.

EMISSIONS CONTROL SYSTEM WARRANTY

Yamaha Motor Corporation, U.S.A. also warrants to the ultimate purchaser and each subsequent purchaser of each Yamaha motorcycle covered by this warranty with a displacement of 50cc or greater, that the vehicle is designed, built, and equipped so as to conform at the time of sale with all U.S. emissions standards applicable at the time of manufacture and that it is free from defects in materials and workmanship which would cause it not to meet these standards within the periods listed immediately below. Failures other than those resulting from defects in material or workmanship which arise solely as a result of owner abuse and/or lack of proper maintenance are not covered by this warranty.

ENGINE DISPLACEMENT

50cc to 169cc
170cc to 279cc
280cc or over

PERIOD

12,000 km (7,465 miles) or five years, whichever occurs first
18,000 km (11,185 miles) or five years, whichever occurs first
30,000 km (18,641 miles) or five years, whichever occurs first

YAMAHA MOTOR CORPORATION, U.S.A. MAKES NO OTHER WARRANTY OF ANY KIND, EXPRESSED OR IMPLIED. ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE WHICH EXCEED THE OBLIGATIONS AND TIME LIMITS STATED IN THIS WARRANTY ARE HEREBY DISCLAIMED BY YAMAHA MOTOR CORPORATION, U.S.A. AND EXCLUDED FROM THIS WARRANTY.

SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. ALSO EXCLUDED FROM THIS WARRANTY ARE ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES INCLUDING LOSS OF USE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSION MAY NOT APPLY TO YOU.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

YAMAHA MOTOR CORPORATION, U.S.A.
P.O. Box 6555
Cypress, California 90630
Customer Relations: 1-800-962-7926

WARRANTY QUESTIONS AND ANSWERS

- Q. What costs are my responsibility during the warranty period?
- A. The customer's responsibility includes all costs of normal maintenance services, non-warranty repairs, accident and collision damages, and oil, oil filters, air filters, spark plugs, and brake shoes.
- Q. What are some examples of "abnormal" strain, neglect, or abuse?
- A. These terms are general and overlap each other in areas. Specific examples include: Running the machine out of oil, sustained high rpm, full-throttle, operating the machine with a broken or damaged part which causes another part to fail, damage or failure due to improper or careless transportation and/or tie-down. If you have any specific questions on operation or maintenance, please contact your dealer for advice.
- Q. Does the warranty cover incidental costs such as towing or transportation due to a failure?
- A. No. The warranty is limited to repair of the machine itself.
- Q. May I perform any or all of the recommended maintenance shown in the Owner's Manual instead of having the dealer do them?
- A. Yes, if you are a qualified mechanic and follow the procedures specified in the Owner's and Service Manual. We do recommend, however, that items requiring special tools or equipment be done by a Yamaha motorcycle dealer.
- Q. Will the warranty be void or cancelled if I do not operate or maintain my new motorcycle exactly as specified in the Owner's Manual?
- A. No. The warranty on a new motorcycle cannot be "voided" or "cancelled." However, if a particular failure is caused by operation or maintenance other than as described in the Owner's Manual, that failure may not be covered under warranty.
- Q. What responsibility does my dealer have under this warranty?
- A. Each Yamaha motorcycle dealer is expected to:
1. Completely set up every new machine before sale.
 2. Explain the operation, maintenance, and warranty requirements to your satisfaction at the time of sale, and upon your request at any later date.
 3. Each Yamaha motorcycle dealer is held responsible for his setup, service and warranty repair work.
- Q. Is the warranty transferable to second owners?
- A. Yes. The remainder of the existing warranty can be transferred upon request. The unit has to be inspected and re-registered by an authorized Yamaha motorcycle dealer for the policy to remain effective.

CUSTOMER SERVICE

If your machine requires warranty service, you must take it to any authorized Yamaha motorcycle dealer within the continental United States. Be sure to bring your warranty registration card or other valid proof of the original date of purchase. If a question or problem arises regarding the warranty, first contact the owner of the dealership. Since all warranty matters are handled at the dealer level, this person is in the best position to help you. If you are still not satisfied and require additional assistance, please write to:

YAMAHA MOTOR CORPORATION, U.S.A.
CUSTOMER RELATIONS DEPARTMENT
P.O. Box 6555
Cypress, California 90630

When contacting Yamaha Motor Corporation, U.S.A., don't forget to include any important information such as names, addresses, model, VIN (vehicle identification number), dates, and receipts.

CHANGE OF ADDRESS

The federal government requires each manufacturer of a motor vehicle to maintain a complete, up-to-date list of all first purchasers against the possibility of a safety-related defect and recall. This list is compiled from the purchase registrations sent to Yamaha Motor Corporation, U.S.A. by the selling dealer at the time of your purchase.

If you should move after you have purchased your new motorcycle, please advise us of your new address by sending a postcard listing your motorcycle model name, VIN number, dealer number (or dealer's name) as it is shown on your warranty card, your name and new mailing address. Mail to:

YAMAHA MOTOR CORPORATION, U.S.A.
1270 Chastain Road
Kennesaw, GA 30144
Attention: Warranty Department

This will ensure that Yamaha Motor Corporation, U.S.A. has an up-to-date registration record in accordance with federal law.

YAMAHA EXTENDED SERVICE (Y.E.S.)

Keep your Yamaha protected even after your limited warranty expires with genuine Yamaha Extended Service (Y.E.S.).

- Y.E.S. is designed and administered by Yamaha Motor Corporation to provide maximum owner satisfaction. It provides uninterrupted factory-backed coverage for extra peace of mind.
- Y.E.S. is flexible. You choose the plan that's right for you: 12 months, 24 months, 36 months or, on certain models, even 48 months beyond your warranty period.
- Y.E.S. is designed and administered by the same Yamaha people who handle your warranty – and it shows in the comprehensive coverage benefits. There are no mileage limitations. Coverage isn't limited to "moving parts" or the "drivetrain" like many other plans. And Y.E.S. covers manufacturing defects just like the warranty. See the sample contract at your Yamaha dealer to see how comforting uninterrupted factory-backed protection can be.
- You don't have to pay anything for covered repairs. There's no deductible to pay, and repairs aren't "pro-rated." You don't have any "out-of-pocket" expenses for covered repairs.
- In addition, Travel and Recreation Interruption Protection (TRIP) is included at no extra cost. TRIP gives you up to \$250 reimbursement per occurrence for any reasonable expenses you incur because your Yamaha needs covered service: replacement vehicle rental, emergency towing, phone calls, even food and lodging when you are away from home. This superb coverage goes into effect when you purchase Y.E.S., so it applies to any warranty repairs as well as covered repairs during your entire Y.E.S. plan period.
- Y.E.S. coverage is honored at any authorized Yamaha dealer nationwide.
- Y.E.S. coverage is transferable to a new owner if you sell or trade-in. That can make your Yamaha much more valuable!

This excellent Y.E.S. plan coverage is only available to Yamaha owners like you, and only while your Yamaha is still within the Yamaha Limited Warranty period. So visit your authorized Yamaha dealer to get all the facts. They can show you how easy it is to protect your investment with Yamaha Extended Service.

Consumer information

We urge you to act now. You'll get the excellent benefits of TRIP coverage right away, and you'll rest easy knowing you'll have strong factory-backed protection even after your Yamaha Limited Warranty expires.

A special note:

If visiting your dealer isn't convenient, contact Yamaha with your VIN number and we'll be happy to help you get the Y.E.S. coverage you need.

Yamaha Service Marketing
P.O. Box 6555
Cypress, CA 90630
1-(866)-YES-EXTD (1-866-937-3983)



A	
ABS.....	5-14
ABS warning light	5-1
Acceleration and deceleration	7-3
Air filter and V-belt case air filter elements	8-14
Auxiliary DC jack.....	5-28
Auxiliary lights.....	8-32
B	
Battery	8-29
Brake fluid, changing	8-24
Brake fluid level, checking.....	8-23
Brake lever, front.....	5-13
Brake lever, rear.....	5-13
Brake levers, lubricating	8-26
Brake/tail light.....	8-33
Braking.....	7-4
C	
Cables, checking and lubricating	8-25
Canister.....	8-9
Care	9-1
Catalytic converters	5-19
Centerstand and sidestand, checking and lubricating.....	8-27
Coolant	8-13
D	
Data recording, vehicle	11-2
Diagnostic connector.....	11-2
Dimmer/Pass switch.....	5-11
E	
Emergency mode.....	8-38
Engine break-in.....	7-5
Engine oil and oil filter element.....	8-9
Engine serial number	11-1
Engine trouble warning light	5-1
F	
Final transmission oil	8-12
Front and rear brake lever free play, checking	8-22
Front and rear brake pads, checking.....	8-23
Front fork, checking.....	8-27
Fuel	5-17
Fuel consumption, tips for reducing	7-4
Fuel tank cap	5-16
Fuel tank overflow hose.....	5-19
Fuses, replacing.....	8-30
H	
Handlebar position, adjusting.....	5-24
Handlebar switches	5-11
Hazard switch	5-12

Headlights	8-32
High beam indicator light	5-1
Horn switch	5-12
I	
Identification numbers.....	11-1
Ignition circuit cut-off system.....	5-26
Indicator lights and warning lights	5-1
K	
Key, handling of smart and mechanical keys.....	4-4
L	
Labels, location	1-1
License plate light bulb, replacing.....	8-34
M	
Main switch	4-8
Maintenance and lubrication, periodic... ..	8-4
Maintenance, emission control system.....	8-3
Maintenance record	11-5
Matte color, caution	9-1
Model label.....	11-1
Multi-function display.....	5-3
N	
Noise regulation	11-4
O	
Operating range of the smart key system.....	4-3
P	
Panel, removing and installing	8-7
Parking	7-5
Part 15 of FCC Rules.....	4-2
Part locations	3-1
S	
Safe-riding points.....	2-5
Safety defects, reporting.....	11-3
Safety information	2-1
Shock absorber assemblies, adjusting.....	5-25
Sidestand	5-26
Smart key	4-6
Smart key battery, replacing	4-7
Smart key system.....	4-4
Smart key system indicator light.....	5-2
Smart key system, troubleshooting.....	8-35
Spark plug, checking	8-8
Specifications	10-1
Speedometer	5-2
Starting off.....	7-3
Starting the engine.....	7-2
Steering, checking.....	8-28

Stop/Run/Start switch.....	5-12
Storage.....	9-4
Storage compartments	5-20

T

Tachometer	5-3
Throttle grip and cable, checking and lubricating	8-26
Throttle grip free play, checking.....	8-18
Tires.....	8-19
Tool kit.....	8-2
Traction control system.....	5-15
Traction control system indicator light...	5-2
TRIP/INFO switch.....	5-12
Troubleshooting	8-35
Troubleshooting charts	8-36
Turn signal indicator lights	5-1
Turn signal light bulb, replacing	8-33
Turn signal switch	5-11

V

Valve clearance	8-19
V-belt, checking	8-25
Vehicle identification number	11-1

W

Warranty, extended.....	11-8
Warranty, limited	11-6
Wheel bearings, checking	8-28
Wheels.....	8-21
Windshield.....	5-22

©2018 Yamaha Motor Corporation, U.S.A. (499500/Dealer Principal/499500)

For your best ownership experience, think **Genuine Yamaha!**

Genuine Yamaha Parts – Genuine Yamaha replacement parts are the exact same parts as the ones originally equipped on your vehicle, providing you with the performance and durability you have come to expect. Why settle for aftermarket parts that may not provide full confidence and satisfaction?

Genuine Yamaha Accessories – Yamaha only offers accessories that meet our high standards for quality and performance. Buy with confidence, knowing your Genuine Yamaha Accessories will fit right and perform right – right out of the box.

Yamalube – Take care of your Yamaha with legendary Yamalube oils, lubricants, and care products. They're formulated and approved by the toughest judges we know: the Yamaha engineering teams that know your Yamaha from the inside out.

Genuine Yamaha Service Manuals – Get the same factory manual for your vehicle that the technicians at your authorized Yamaha dealer use. Service manuals are available through your Yamaha dealer or you can order them directly through yamahapubs.com (for US consumers only).

Genuine Yamaha products are available only from your Yamaha dealer.

Find out more at:

For US consumers, please visit yamaha-motor.com

For Canadian consumers, please visit yamaha-motor.ca

©2018 Yamaha Motor Corporation, U.S.A. (499500/Dealer Principal/499500)

©2018 Yamaha Motor Corporation, U.S.A. (499500/Dealer Principal/499500)

©2018 Yamaha Motor Corporation, U.S.A. (499500/Dealer Principal/499500)

©2018 Yamaha Motor Corporation, U.S.A. (499500/Dealer Principal/499500)



YAMAHA

PRINTED IN INDONESIA
2017.05